

| PART # | ENG # | NOMENCLATURE |
|----------------|--------|--------------------------|
| 10-60563-26 | BOEING | FLEX TUBE ASSY |
| 1210144-101 | BOEING | APU FLEXIBLE DUCT |
| 221-5303-505 | BOEING | DUCT ASSY |
| 332T4303-43 | BOEING | TUBE ASSY |
| 332T4326-1 | BOEING | 8TH STAGE PNEUMATIC DUCT |
| 332T4327-1 | BOEING | DUCT ASSY |
| 332T4313-14 | BOEING | DUCT ASSY |
| 60B00254-36 | BOEING | FLEX TUBE ASSY |
| 60B90135-12 | BOEING | FLEX TUBE ASSY |
| 65-22441-31 | BOEING | DUCT ASSY |
| 65-22441-31MOD | BOEING | DUCT ASSY |
| 65-22441-34 | BOEING | DUCT ASSY |
| 65-22441-43 | BOEING | MANIFOLD ASSY |
| 65-22442-2 | BOEING | DUCT ASSY |
| 65-22444-19 | BOEING | DUCT ASSY |
| 65-22444-20 | BOEING | DUCT ASSY |
| 65-22444-21 | BOEING | DUCT ASSY |
| 65-22444-22 | BOEING | 8TH STAGE PNEUMATIC DUCT |
| 65-22446-10 | BOEING | DUCT ASSY |
| 65-22446-2 | BOEING | DUCT ASSY |
| 65-22450-14 | BOEING | DUCT ASSY |
| 65-22450-26 | BOEING | DUCT ASSY |
| 65-22450-29 | BOEING | DUCT ASSY |
| 65-22450-31 | BOEING | DUCT ASSY |
| 65-22453-11 | BOEING | DUCT ASSY |
| 65-22453-20 | BOEING | DUCT ASSY |
| 65-22456-26 | BOEING | DUCT ASSY |
| 65-22751-14 | BOEING | DUCT ASSY |
| 65-22754-19 | BOEING | DUCT ASSY |
| 65-22754-30 | BOEING | DUCT ASSY |
| 65-26738-22 | BOEING | DUCT ASSY |
| 65-46869-4 | BOEING | DUCT ASSY |
| 65-83863-30 | BOEING | DUCT ASSY |
| 65-53863-32 | BOEING | DUCT ASSY |
| 65-53863-802 | BOEING | DUCT ASSY |
| 65-53864-800 | BOEING | DUCT ASSY |
| 65-58123-2 | BOEING | DUCT ASSY |
| 65-58123-7 | BOEING | DUCT ASSY |
| 65-69311-1 | BOEING | TUBE ASSY |
| 69-44634-1 | BOEING | STARTER DUCT |



BOEING CAPABILITIES

Rev. No. 11 (Date 01-14-11)

Page 2 of 2

| PART # | ENG # | NOMENCLATURE |
|------------|--------|-------------------------------|
| 69-44634-4 | BOEING | DUCT ASSY |
| 69-45174-1 | BOEING | 8TH STAGE RIGHT HAND MANIFOLD |
| 108034-11 | BOEING | TUBE HOSE ASSY |
| 109003-2 | BOEING | HOSE ASSY |