

PART #	ENG #	NOMENCLATURE
110013	CF6-80E	TUBE-FUEL SERVO HEATER
110013	CF6-80E	TUBE-FUEL SERVO HEATER
110591	CF6-80E	HOSE-UPPER FAN DRAIN
110591	CF6-80E	HOSE-UPPER FAN DRAIN
110640	CF6-80E	TUBE-FUEL SERVO HEATER
110640	CF6-80E	TUBE-FUEL SERVO HEATER
113691	CF6-80E	TUBE AND HOSE-OIL IDG COOLING
113691	CF6-80E	TUBE AND HOSE-OIL IDG
113764	CF6-80E	TUBE-HOSE AIR SIGNAL
113912	CF6-80E	TUBE AND HOSE-OIL
113912	CF6-80E	TUBE AND HOSE-OIL
113956	CF6-80E	TUBE AND HOSE-FUEL
113956	CF6-80E	TUBE AND HOSE-FUEL FUEL/OIL COOLER TO FUEL PUMP
113958	CF6-80E	TUBE AND HOSE-FUEL VBV ACTUATOR HEAD END
113958	CF6-80E	TUBE AND HOSE-FUEL VBV ACTUATOR HEAD END
113959	CF6-80E	TUBE AND HOSE-FUEL VBV ACTUATOR ROD END
113959	CF6-80E	TUBE AND HOSE-FUEL VBV ACTUATOR ROD END
113961	CF6-80E	TUBE AND HOSE-FUEL VSV ACTUATOR ROD END
113961	CF6-80E	TUBE AND HOSE-FUEL VSV ACTUATOR ROD END
114312	CF6-80E	HOSE-FUEL HMU TO
114312	CF6-80E	HOSE-FUEL HMU TO FUEL/OIL COOLER
114545	CF6-80E	TUBE-HOSE
114545	CF6-80E	TUBE-HOSE
114566	CF6-80E	TUBE AND HOSE-OIL D
114566	CF6-80E	TUBE AND HOSE-OIL D
114569	CF6-80E	TUBE-HOSE OIL
114585	CF6-80E	TUBE AND HOSE-FUEL VSV ACTUATOR HEAD END
114585	CF6-80E	TUBE AND HOSE-FUEL VSV ACTUATOR HEAD END
114596	CF6-80E	TUBE
114596	CF6-80E	TUBE
115200	CF6-80E	TUBE AND HOSE-FUEL
115200	CF6-80E	TUBE AND HOSE-FUEL
115207	CF6-80E	TUBE-FUEL SERVO HEATER
115207	CF6-80E	TUBE-FUEL SERVO HEATER
115518	CF6-80E	TUBE-FUEL SUPPLY
115518	CF6-80E	TUBE-FUEL SUPPLY
115519	CF6-80E	TUBE-FUEL HOSE
115887	CF6-80E	TUBE AND HOSE-FUEL, HEAT EXCHANGER TO HMU
115887	CF6-80E	TUBE AND HOSE-FUEL, HEAT EXCHANGER TO HMU
116376	CF6-80E	TUBE AND HOSE-OIL D

PART #	ENG #	NOMENCLATURE
116376	CF6-80E	TUBE AND HOSE-OIL D
108292-9	CF6-80E	HOSE-OIL
108292-9	CF6-80E	HOSE-OIL
108292-9	CF6-80E	HOSE-OIL
108292-9	CF6-80E	HOSE-OIL
108292-9	CF6-80E	HOSE-OIL
110560-19	CF6-80E	HOSE
113134C0086DAB	CF6-80E	HOSE-TEFLON
113134C0086DAB	CF6-80E	HOSE-TEFLON
113134C0104DAB	CF6-80E	HOSE-TEFLON
113134E0110DAA	CF6-80E	HOSE-TEFLON
113134E0110DAA	CF6-80E	HOSE-TEFLON
113134E0110DAB	CF6-80E	HOSE-TEFLON
113134E0110DAB	CF6-80E	HOSE-TEFLON
113134E0110DAB	CF6-80E	HOSE-TEFLON
113134E0110DAB	CF6-80E	HOSE-TEFLON
113134E0110DAB	CF6-80E	HOSE-TEFLON
113134E0111DAA	CF6-80E	HOSE-TEFLON
113134E0111DAA	CF6-80E	HOSE-TEFLON
113134E0111DAB	CF6-80E	HOSE-TEFLON
113134E0111DAB	CF6-80E	HOSE-TEFLON
113240D0090DAB	CF6-80E	HOSE-TEFLON
113910-513	CF6-80E	HOSE
113910-515	CF6-80E	HOSE
113910-517	CF6-80E	HOSE
113910-521	CF6-80E	HOSE
113910-523	CF6-80E	HOSE
113910-525	CF6-80E	HOSE
113910-527	CF6-80E	HOSE
114034-1	CF6-80E	HOSE-OIL
114034-1	CF6-80E	HOSE-OIL
114151-1	CF6-80E	TUBE-FUEL SUPPLY
114151-1	CF6-80E	TUBE-FUEL SUPPLY
114151-2	CF6-80E	TUBE-FUEL HOSE
114151-2	CF6-80E	TUBE-FUEL HOSE
115207-1	CF6-80E	TUBE-FUEL SERVO HEATER
115207-1	CF6-80E	TUBE
118134E0110DAB	CF6-80E	HOSE-TEFLON
118134E0110DAB	CF6-80E	HOSE-TEFLON
118134E0111DAB	CF6-80E	HOSE-TEFLON
118134E0111DAB	CF6-80E	HOSE-TEFLON
1290M21G01	CF6-80E	DUCT-AIR LP RECOUP AFT

PART #	ENG #	NOMENCLATURE
1290M21G01	CF6-80E	DUCT-AIR LP RECOUP AFT
1290M22G04	CF6-80E	TUBE-LP RECOUP FWD AIR
1290M22G04	CF6-80E	TUBE-LP RECOUP FWD AIR
1290M23G06	CF6-80E	TUBE-LP RECOUP FWD AIR
1290M23G06	CF6-80E	TUBE-LP RECOUP FWD AIR
1293M74P01	CF6-80E	HOSE-UPPER FAN DRAIN
1293M74P01	CF6-80E	HOSE-UPPER FAN DRAIN
1293M74P02	CF6-80E	HOSE-UPPER FAN DRAIN
1293M74P02	CF6-80E	HOSE-UPPER FAN DRAIN
1293M74P03	CF6-80E	HOSE-UPPER FAN DRAIN
1293M74P03	CF6-80E	HOSE-UPPER FAN DRAIN
1293M74P04	CF6-80E	HOSE-UPPER FAN DRAIN
1293M74P04	CF6-80E	HOSE-UPPER FAN DRAIN
1303M31G12	CF6-80E	MANIFOLD-FUEL LEFT SIDE
1303M31G12	CF6-80E	MANIFOLD-FUEL LEFT SIDE
1303M32G12	CF6-80E	MANIFOLD-FUEL RIGHT SIDE
1303M32G12	CF6-80E	MANIFOLD-FUEL RIGHT SIDE
1304M50G01	CF6-80E	MANIFOLD-FWD
1304M50G01	CF6-80E	TUBE-EXPANDABLE
1309M45G01	CF6-80E	FUEL TUBE-PYLON DR UPPER
1309M78G10	CF6-80E	DUCT-AIR WYE
1321M15G01	CF6-80E	TUBE-FUEL
1321M15G01	CF6-80E	TUBE-FUEL
1321M73G02	CF6-80E	TUBE-COOLING
1332M15G01	CF6-80E	TUBE-OIL
1332M15G01	CF6-80E	TUBE-OIL
1332M50P01	CF6-80E	TUBE
1332M50P01	CF6-80E	TUBE
1332M50P02	CF6-80E	TUBE
1332M50P02	CF6-80E	TUBE
1332M50P02	CF6-80E	TUBE
1332M50P02	CF6-80E	TUBE
1332M50P03	CF6-80E	TUBE
1332M50P03	CF6-80E	TUBE
1332M50P03	CF6-80E	TUBE
1332M50P03	CF6-80E	TUBE
1332M50P04	CF6-80E	TUBE
1332M50P04	CF6-80E	TUBE
1332M50P09	CF6-80E	TUBE
1332M50P09	CF6-80E	TUBE

PART #	ENG #	NOMENCLATURE
1332M50P09	CF6-80E	TUBE
1332M50P09	CF6-80E	TUBE
1332M50P10	CF6-80E	TUBE
1332M50P10	CF6-80E	TUBE
1332M50P12	CF6-80E	TUBE
1332M50P12	CF6-80E	TUBE
1335M92G01	CF6-80E	MANIFOLD-OIL, A SUMP AND TGB SUPPLY
1335M92G01	CF6-80E	MANIFOLD-OIL, A SUMP AND TGB SUPPLY
1335M94G01	CF6-80E	TUBE-TGB OIL SUPPLY
1335M94G01	CF6-80E	TUBE-TGB OIL SUPPLY
1339M39G05	CF6-80E	TUBE-AIR, CORE COWL COOLING
1339M39G05	CF6-80E	TUBE-AIR, CORE COWL COOLING
1346M17G06	CF6-80E	MANIFOLD-AIR, CORE COWL COOLING
1346M17G06	CF6-80E	MANIFOLD-AIR, CORE COWL COOLING
1349M43G01	CF6-80E	TUBE-OIL B SUMP SCAV
1349M43G01	CF6-80E	TUBE-OIL B SUMP SCAV
1349M43G02	CF6-80E	TUBE-OIL B SUMP SCAV
1349M43G02	CF6-80E	TUBE-OIL B SUMP SCAV
1370M75G03	CF6-80E	TUBE-DRAIN
1370M75G03	CF6-80E	TUBE-DRAIN
13841-505	CF6-80E	DUCT ASSY
1442M21G01	CF6-80E	TUBE-UNDER COWL COOLING
1442M21G01	CF6-80E	TUBE-UNDER COWL COOLING AIR
1446M15P01	CF6-80E	TUBE AND HOSE-FUEL,HEAT EXCHANGER TO HMU
1446M15P01	CF6-80E	TUBE AND HOSE-FUEL, HEAT EXCHANGER TO HMU
1446M15P04	CF6-80E	TUBE-FUEL SERVO HEATER
1446M15P04	CF6-80E	TUBE-FUEL SERVO HEATER
1446M24G05	CF6-80E	TUBE-AIR SUPPLY HP
1446M24G05	CF6-80E	TUBE-AIR SUPPLY HP RECOUP LS
1446M49G01	CF6-80E	TUBE-FUEL
1446M49G01	CF6-80E	TUBE-FUEL
1456M65G01	CF6-80E	TUBE-AIR, BORE
1456M65G01	CF6-80E	TUBE-AIR, BORE
1456M69G01	CF6-80E	TUBE-AIR, BORE
1456M69G01	CF6-80E	TUBE-AIR, BORE
1456M71G02	CF6-80E	TUBE-AIR, BORE
1456M71G02	CF6-80E	TUBE-AIR, BORE
1456M77G02	CF6-80E	TUBE-AIR, BORE
1457M50G01	CF6-80E	FUEL MANIFOLD
1457M50G01	CF6-80E	FUEL MANIFOLDS

PART #	ENG #	NOMENCLATURE
1457M50G01	CF6-80E	OIL SCAVANGE TUBES
1457M50G01	CF6-80E	B SUMP VENT TUBES
1457M50G01	CF6-80E	B SUMP AIR TUBES
1457M50G03	CF6-80E	FUEL MANIFOLD
1457M50G03	CF6-80E	FUEL MANIFOLDS
1457M50G03	CF6-80E	OIL SCAVANGE TUBES
1457M50G03	CF6-80E	B SUMP VENT TUBES
1457M50G03	CF6-80E	B SUMP AIR TUBES
1457M50G07	CF6-80E	FUEL MANIFOLD
1457M50G07	CF6-80E	FUEL MANIFOLDS
1457M50G07	CF6-80E	OIL SCAVANGE TUBES
1457M50G07	CF6-80E	B SUMP VENT TUBES
1457M50G07	CF6-80E	B SUMP AIR TUBES
1457M50G08	CF6-80E	FUEL MANIFOLD
1457M50G08	CF6-80E	FUEL MANIFOLDS
1457M50G08	CF6-80E	OIL SCAVANGE TUBES
1457M50G08	CF6-80E	B SUMP VENT TUBES
1457M50G08	CF6-80E	B SUMP AIR TUBES
1457M50G09	CF6-80E	FUEL MANIFOLD
1457M50G09	CF6-80E	FUEL MANIFOLDS
1457M50G09	CF6-80E	OIL SCAVANGE TUBES
1457M50G09	CF6-80E	B SUMP VENT TUBES
1457M50G09	CF6-80E	B SUMP AIR TUBES
1457M80G01	CF6-80E	7TH STAGE COOLING MANIFOLD
1457M80G01	CF6-80E	AIR RECOUP TUBES
1457M80G01	CF6-80E	COOLING MANIFOLD
1457M80G01	CF6-80E	OIL SUPPLY TUBES
1457M80G01	CF6-80E	OIL SCAVANGE TUBES
1457M80G02	CF6-80E	7TH STAGE COOLING MANIFOLD
1457M80G02	CF6-80E	AIR RECOUP TUBES
1457M80G02	CF6-80E	COOLING MANIFOLD
1457M80G02	CF6-80E	OIL SUPPLY TUBES
1457M80G02	CF6-80E	OIL SCAVANGE TUBES
1457M80G03	CF6-80E	7TH STAGE COOLING MANIFOLD
1457M80G03	CF6-80E	AIR RECOUP TUBES
1457M80G03	CF6-80E	COOLING MANIFOLD
1457M80G03	CF6-80E	OIL SUPPLY TUBES
1457M80G03	CF6-80E	OIL SCAVANGE TUBES
1457M84G01	CF6-80E	11TH STAGE AIR TUBE
1457M84G02	CF6-80E	11TH STAGE AIR TUBE

PART #	ENG #	NOMENCLATURE
1457M85G01	CF6-80E	FUEL SIGNAL TUBES
1457M85G02	CF6-80E	FUEL SIGNAL TUBES
1457M90G01	CF6-80E	11TH STAGE AIR TUBE
1469M28G03	CF6-80E	TUBE-LP RECOUP
1469M28G03	CF6-80E	TUBE-LP RECOUP
1469M72G01	CF6-80E	TUBE-AIR, BORE
1469M72G01	CF6-80E	TUBE-AIR, BORE
1469M74G01	CF6-80E	TUBE-AIR, BORE
1469M74G01	CF6-80E	TUBE-AIR, BORE
1469M74G02	CF6-80E	TUBE-AIR, BORE
1469M74G02	CF6-80E	TUBE-AIR, BORE
1469M86G01	CF6-80E	TUBE-AIR, BORE
1469M86G01	CF6-80E	TUBE-AIR, BORE
1473M25G10	CF6-80E	MANIFOLD-HPT ACTIVE CLEARANCE CONTROL
1473M25G10	CF6-80E	MANIFOLD-HPT ACTIVE CLEARANCE CONTROL
1473M25G11	CF6-80E	MANIFOLD-HPT ACTIVE CLEARANCE CONTROL
1473M25G11	CF6-80E	MANIFOLD-HPT ACTIVE CLEARANCE CONTROL
1473M25G12	CF6-80E	MANIFOLD-HPT ACTIVE CLEARANCE CONTROL
1473M25G12	CF6-80E	MANIFOLD-HPT ACTIVE CLEARANCE CONTROL
1473M25G13	CF6-80E	MANIFOLD-HPT ACTIVE CLEARANCE CONTROL
1473M25G13	CF6-80E	MANIFOLD-HPT ACTIVE CLEARANCE CONTROL
1473M25G14	CF6-80E	MANIFOLD-HPT ACTIVE CLEARANCE CONTROL
1473M25G14	CF6-80E	MANIFOLD-HPT ACTIVE CLEARANCE CONTROL
1473M25G15	CF6-80E	MANIFOLD-HPT ACTIVE CLEARANCE CONTROL
1473M25G15	CF6-80E	MANIFOLD-HPT ACTIVE CLEARANCE CONTROL
1473M25G16	CF6-80E	MANIFOLD-HPT ACTIVE CLEARANCE CONTROL
1473M25G16	CF6-80E	MANIFOLD-HPT ACTIVE CLEARANCE CONTROL
1473M25G17	CF6-80E	MANIFOLD-HPT ACTIVE CLEARANCE CONTROL
1473M25G17	CF6-80E	MANIFOLD-HPT ACTIVE CLEARANCE CONTROL
1473M26G02	CF6-80E	MANIFOLD-AIR, HPT ACTIVE CLEARANCE CONTROL
1473M26G02	CF6-80E	MANIFOLD-AIR, HPT ACTIVE CLEARANCE CONTROL
1473M26G03	CF6-80E	MANIFOLD-AIR, HPT ACTIVE CLEARANCE CONTROL
1473M26G03	CF6-80E	MANIFOLD-AIR, HPT ACTIVE CLEARANCE CONTROL
1491M20G01	CF6-80E	TUBE-ACCY GRBX OIL SCAV
1491M20G01	CF6-80E	TUBE-ACCY GRBX OIL SCAV
1491M20G03	CF6-80E	TUBE-ACCY GRBX OIL SCAV
1491M20G03	CF6-80E	TUBE-ACCY GRBX OIL SCAV
1491M20G04	CF6-80E	TUBE-ACCY GRBX OIL SCAV
1491M20G04	CF6-80E	TUBE-ACCY GRBX OIL SCAV
1491M20G07	CF6-80E	TUBE-ACCY GRBX OIL SCAV

PART #	ENG #	NOMENCLATURE
1491M20G07	CF6-80E	TUBE-ACCY GRBX OIL SCAV
1581M56P01	CF6-80E	TUBE AND HOSE-OIL IDG COOLING
1581M56P01	CF6-80E	TUBE AND HOSE-OIL IDG
1581M56P02	CF6-80E	TUBE AND HOSE-OIL IDG COOLING
1581M56P02	CF6-80E	TUBE AND HOSE-OIL IDG
1581M56P03	CF6-80E	TUBE AND HOSE-OIL IDG COOLING
1581M56P03	CF6-80E	TUBE AND HOSE-OIL IDG
1581M56P04	CF6-80E	TUBE AND HOSE-OIL IDG COOLING
1581M56P04	CF6-80E	TUBE AND HOSE-OIL IDG
1581M78G07	CF6-80E	DUCT-AIR
1606M20P01	CF6-80E	TUBE-HOSE AIR SIGNAL
1606M20P02	CF6-80E	TUBE-HOSE AIR SIGNAL
1606M20P03	CF6-80E	TUBE-HOSE AIR SIGNAL
1606M20P04	CF6-80E	TUBE-HOSE AIR SIGNAL
1606M22G01	CF6-80E	TUBE-OIL AIR/OIL COOLER
1606M22G01	CF6-80E	TUBE-OIL AIR/OIL COOLER
1619M45G02	CF6-80E	DUCT-AIR INLET HPT ACC
1619M45G02	CF6-80E	DUCT-AIR INLET HPT ACC
1619M46G06	CF6-80E	TUBE-AIR HPT SUPPLY
1619M46G06	CF6-80E	TUBE-AIR HPT SUPPLY
1639M34G02	CF6-80E	TUBE-CTR VENT
1642M54G02	CF6-80E	MANIFOLD-AIR HPT ACC
1642M54G02	CF6-80E	MANIFOLD-AIR HPT ACC
1642M54G03	CF6-80E	MANIFOLD-AIR HPT ACC
1642M54G03	CF6-80E	MANIFOLD-AIR HPT ACC
1642M54G04	CF6-80E	MANIFOLD-AIR HPT ACC
1642M54G04	CF6-80E	MANIFOLD-AIR HPT ACC
1642M54G08	CF6-80E	MANIFOLD-AIR HPT ACC
1642M54G08	CF6-80E	MANIFOLD-AIR HPT ACC
1642M54G09	CF6-80E	MANIFOLD-AIR HPT ACC
1642M54G09	CF6-80E	MANIFOLD-AIR HPT ACC
1649M69G01	CF6-80E	TUBE-OIL SPLY
1661M15G02	CF6-80E	TUBE-AIR 11TH STAGE A
1661M15G02	CF6-80E	TUBE-AIR 11TH STAGE A
1661M15G02	CF6-80E	TUBE-AIR 11TH STAGE A
1661M17G02	CF6-80E	TUBE-AIR 11TH STAGE B
1661M17G02	CF6-80E	TUBE-AIR 11TH STAGE B
1661M21G02	CF6-80E	TUBE-AIR 11TH STAGE C
1661M21G02	CF6-80E	TUBE-AIR 11TH STAGE C
1661M21G02	CF6-80E	TUBE-AIR 11TH STAGE C

PART #	ENG #	NOMENCLATURE
1661M23G02	CF6-80E	TUBE-AIR 11TH STAGE D
1661M23G02	CF6-80E	TUBE-AIR 11TH STAGE D
1661M23G02	CF6-80E	TUBE-AIR 11TH STAGE D
1661M59G01	CF6-80E	TUBE-AIR BORE COOLING
1661M59G01	CF6-80E	TUBE-AIR BORE COOLING,STRUT 6
1662M64G01	CF6-80E	TUBE-AIR
1662M64G01	CF6-80E	TUBE-AIR
1678M62G01	CF6-80E	TUBE-AIR CURTAIN RIGHT SIDE
1678M62G01	CF6-80E	TUBE-AIR CURTAIN RIGHT SIDE
1678M62G03	CF6-80E	TUBE-AIR CURTAIN RIGHT SIDE
1678M62G03	CF6-80E	TUBE-AIR CURTAIN RIGHT SIDE
1678M80P05	CF6-80E	TUBE AND HOSE-OIL
1678M80P05	CF6-80E	TUBE AND HOSE-OIL
1678M80P06	CF6-80E	TUBE AND HOSE-OIL
1678M80P06	CF6-80E	TUBE AND HOSE-OIL
1678M80P07	CF6-80E	TUBE AND HOSE-OIL
1678M80P07	CF6-80E	TUBE AND HOSE-OIL
1678M80P08	CF6-80E	TUBE AND HOSE-OIL
1678M80P08	CF6-80E	TUBE AND HOSE-OIL
1678M82G01	CF6-80E	TUBE-OIL N1 SCAV
1684M32G02	CF6-80E	TUBE-AIR B SUMP PRESS
1684M32G02	CF6-80E	TUBE-AIR B SUMP PRESS
1684M79G01	CF6-80E	TUBE-LPT CLEARANCE CONT
1684M79G01	CF6-80E	TUBE-LPT CLEARANCE CONT SPLY FUEL
1684M81G01	CF6-80E	TUBE-HP/LP CLEARANCE
1684M81G01	CF6-80E	TUBE-HP/LP CLEARANCE CONT RTN FUEL
1700M34G01	CF6-80E	MANIFOLD FUEL AND DRAIN
1700M34G01	CF6-80E	MANIFOLD FUEL AND DRAIN
1700M35G01	CF6-80E	MANIFOLD-FUEL AND DRAIN
1700M35G01	CF6-80E	MANIFOLD-FUEL AND DRAIN
1700M35G02	CF6-80E	MANIFOLD-FUEL AND DRAIN
1700M35G02	CF6-80E	MANIFOLD-FUEL AND DRAIN
1700M67G01	CF6-80E	TUBE-SUPPLY OIL D
1700M67G01	CF6-80E	TUBE-SUPPLY OIL D
1700M96G01	CF6-80E	TUBE-FUEL
1700M96G01	CF6-80E	TUBE-FUEL
1701M33G01	CF6-80E	TUBE-AIR 11TH STAGE
1701M33G01	CF6-80E	TUBE-AIR 11TH STAGE CONTROL VALVE
1701M75G02	CF6-80E	TUBE-AIR LPT SUPPLY
1701M77G03	CF6-80E	MANIFOLD-AIR LS

PART #	ENG #	NOMENCLATURE
1701M77G03	CF6-80E	MANIFOLD-AIR LS
1701M79G03	CF6-80E	MANIFOLD-AIR RS
1701M79G03	CF6-80E	MANIFOLD-AIR RS
1701M79G04	CF6-80E	MANIFOLD-AIR RS
1701M79G04	CF6-80E	MANIFOLD-AIR RS
1701M85G02	CF6-80E	TUBE-AIR HP RECOUP
1701M85G02	CF6-80E	TUBE-AIR HP RECOUP SUPPLY RIGHT SIDE
1702M10G02	CF6-80E	TUBE-AIR SUPPLY 7TH
1702M54P01	CF6-80E	TUBE AND HOSE-FUEL VBV ACTUATOR HEAD END
1702M54P01	CF6-80E	TUBE AND HOSE-FUEL VBV ACTUATOR HEAD END
1702M54P02	CF6-80E	TUBE AND HOSE-FUEL VBV ACTUATOR HEAD END
1702M54P02	CF6-80E	TUBE AND HOSE-FUEL VBV ACTUATOR HEAD END
1702M54P03	CF6-80E	TUBE AND HOSE-FUEL VBV ACTUATOR HEAD END
1702M54P03	CF6-80E	TUBE AND HOSE-FUEL VBV ACTUATOR HEAD END
1702M54P04	CF6-80E	TUBE AND HOSE-FUEL VBV ACTUATOR HEAD END
1702M54P04	CF6-80E	TUBE AND HOSE-FUEL VBV ACTUATOR HEAD END
1702M56P01	CF6-80E	TUBE AND HOSE-FUEL VBV ACTUATOR ROD END
1702M56P01	CF6-80E	TUBE AND HOSE-FUEL VBV ACTUATOR ROD END
1702M56P02	CF6-80E	TUBE AND HOSE-FUEL VBV ACTUATOR ROD END
1702M56P02	CF6-80E	TUBE AND HOSE-FUEL VBV ACTUATOR ROD END
1702M56P03	CF6-80E	TUBE AND HOSE-FUEL VBV ACTUATOR ROD END
1702M56P03	CF6-80E	TUBE AND HOSE-FUEL VBV ACTUATOR ROD END
1702M56P04	CF6-80E	TUBE AND HOSE-FUEL VBV ACTUATOR ROD END
1702M56P04	CF6-80E	TUBE AND HOSE-FUEL VBV ACTUATOR ROD END
1702M60P01	CF6-80E	TUBE AND HOSE-FUEL VSV ACTUATOR ROD END
1702M60P01	CF6-80E	TUBE AND HOSE-FUEL VSV ACTUATOR ROD END
1702M60P02	CF6-80E	TUBE AND HOSE-FUEL VSV ACTUATOR ROD END
1702M60P02	CF6-80E	TUBE AND HOSE-FUEL VSV ACTUATOR ROD END
1702M60P03	CF6-80E	TUBE AND HOSE-FUEL VSV ACTUATOR ROD END
1702M60P03	CF6-80E	TUBE AND HOSE-FUEL VSV ACTUATOR ROD END
1702M60P04	CF6-80E	TUBE AND HOSE-FUEL VSV ACTUATOR ROD END
1702M60P04	CF6-80E	TUBE AND HOSE-FUEL VSV ACTUATOR ROD END
1702M92G01	CF6-80E	TUBE-AIR PS3 CORE AFT
1702M92G01	CF6-80E	TUBE-AIR PS3 CORE AFT
1702M92G02	CF6-80E	TUBE-AIR PS3 CORE AFT
1702M92G02	CF6-80E	TUBE-AIR PS3 CORE AFT
1706M80G24	CF6-80E	MANIFOLD-CLG,LPT
1706M80G24	CF6-80E	MANIFOLD-CLG,LPT
1706M80G27	CF6-80E	MANIFOLD-CLG,LPT
1706M80G27	CF6-80E	MANIFOLD-CLG,LPT

PART #	ENG #	NOMENCLATURE
1706M80G28	CF6-80E	MANIFOLD-CLG,LPT
1706M80G28	CF6-80E	MANIFOLD-CLG,LPT
1706M80G36	CF6-80E	MANIFOLD-CLG,LPT
1706M80G36	CF6-80E	MANIFOLD-CLG
1706M80G36	CF6-80E	MANIFOLD-CLG,LPT
1706M80G36	CF6-80E	MANIFOLD-CLG,LPT
1706M80G37	CF6-80E	MANIFOLD-CLG,LPT
1706M80G37	CF6-80E	MANIFOLD-CLG,LPT
1714M10G01	CF6-80E	TUBE-AIR PS3 CORE AFT
1714M10G01	CF6-80E	TUBE-AIR PS3 CORE AFT
1714M10G02	CF6-80E	TUBE-AIR PS3 CORE AFT
1714M10G02	CF6-80E	TUBE-AIR PS3 CORE AFT
1714M35G02	CF6-80E	TUBE-AIR 11TH STAGE E
1714M35G02	CF6-80E	TUBE-AIR 11TH STAGE E
1715M23G01	CF6-80E	TUBE-AIR BORE COOLING,L.H.
1715M23G01	CF6-80E	TUBE-AIR BORE COOLING,L.H.
1715M28G01	CF6-80E	MANIFOLD-AIR HIGH PRESS
1715M28G01	CF6-80E	MANIFOLD-AIR HIGH PRESS 11TH STAGE LOWER RIGHT SIDE
1715M32G01	CF6-80E	MANIFOLD-AIR HIGH PRESS 11TH STAGE LOWER LEFT SIDE
1715M34G01	CF6-80E	MANIFOLD-AIR HIGH PRESS
1715M34G01	CF6-80E	MANIFOLD-AIR HIGH PRESS 11TH STAGE UPPER LEFT SIDE
1715M65G01	CF6-80E	TUBE-OIL FLTR
1715M65G01	CF6-80E	TUBE-OIL FLTR DIFFERENTIAL PRESS SW
1715M77G01	CF6-80E	MANIFOLD-AIR HIGH PRESS 11TH STAGE UPPER RIGHT SIDE
1715M95G01	CF6-80E	TUBE-AIR DELTA P LONG
1715M95G02	CF6-80E	TUBE-AIR DELTA P LONG
1754M73G01	CF6-80E	TUBE-OIL
1754M77G01	CF6-80E	TUBE-SCAV TRF
1757M12G01	CF6-80E	TUBE-FUEL
1757M12G02	CF6-80E	TUBE-FUEL DRAIN HPT
1757M12G02	CF6-80E	TUBE-FUEL DRAIN HPT
1757M12G02	CF6-80E	TUBE-FUEL DRAIN HPT CONTROL VALVE
1757M12G02	CF6-80E	TUBE-FUEL DRAIN HPT CONTROL VALVE
1757M50P01	CF6-80E	TUBE AND HOSE-FUEL
1757M50P01	CF6-80E	TUBE AND HOSE-FUEL FUEL/OIL COOLER TO FUEL PUMP
1757M50P02	CF6-80E	TUBE AND HOSE-FUEL
1757M50P02	CF6-80E	TUBE AND HOSE-FUEL FUEL/OIL COOLER TO FUEL PUMP
1757M50P03	CF6-80E	TUBE AND HOSE-FUEL
1757M50P03	CF6-80E	TUBE AND HOSE-FUEL FUEL/OIL COOLER TO FUEL PUMP
1757M50P04	CF6-80E	TUBE AND HOSE-FUEL

PART #	ENG #	NOMENCLATURE
1757M50P04	CF6-80E	TUBE AND HOSE-FUEL FUEL/OIL COOLER TO FUEL PUMP
1760M88G02	CF6-80E	MANIFOLD-UPR DR
1760M88G02	CF6-80E	MANIFOLD-UPR DR
1760M88G03	CF6-80E	MANIFOLD-UPR DR
1760M88G03	CF6-80E	MANIFOLD-UPR DR
1761M19G01	CF6-80E	MANIFOLD-DRAIN FUEL VSV ACTUATOR
1761M19G01	CF6-80E	MANIFOLD-DRAIN FUEL VSV ACTUATOR
1761M21G01	CF6-80E	MANIFOLD-DRAIN FUEL VSV ACTUATOR
1761M21G01	CF6-80E	MANIFOLD-DRAIN FUEL VBV ACTUATOR
1761M50G03	CF6-80E	DUCT-AIR LPT ACC
1761M69G01	CF6-80E	MANIFOLD-FWD
1761M69G01	CF6-80E	MANIFOLD-FWD
1761M69G02	CF6-80E	MANIFOLD-FWD
1761M69G02	CF6-80E	MANIFOLD-FWD
1761M79G01	CF6-80E	TUBE-OIL C-SUMP SCAV
1761M79G01	CF6-80E	TUBE-OIL C-SUMP SCAV
1761M83G01	CF6-80E	TUBE-OIL B SCAV FWD
1761M83G01	CF6-80E	TUBE-OIL B SCAV FWD
1761M83G02	CF6-80E	TUBE-OIL B SCAV FWD
1761M83G02	CF6-80E	TUBE-OIL B SCAV FWD
1761M85G01	CF6-80E	TUBE-C SUMP SCAV OIL
1761M85G01	CF6-80E	TUBE-C SUMP SCAV OIL
1761M87G01	CF6-80E	TUBE AND HOSE-OIL D
1761M87G01	CF6-80E	TUBE AND HOSE-OIL D
1761M94P05	CF6-80E	HOSE-OIL
1761M94P05	CF6-80E	HOSE-OIL
1761M94P06	CF6-80E	HOSE-OIL
1761M94P06	CF6-80E	HOSE-OIL
1761M94P07	CF6-80E	HOSE-OIL
1761M94P07	CF6-80E	HOSE-OIL
1761M94P08	CF6-80E	HOSE-OIL
1761M94P08	CF6-80E	HOSE-OIL
1772M16G01	CF6-80E	TUBE-FUEL PMP DR
1772M16G01	CF6-80E	TUBE-FUEL PMP DR
1772M62G01	CF6-80E	TUBE-FUEL
1772M64G01	CF6-80E	TUBE-FUEL
1772M76G02	CF6-80E	MANIFOLD-AIR CORE COMPARTMENT COOLING
1773M16G01	CF6-80E	TUBE-OIL B GEAR BOX
1773M16G01	CF6-80E	TUBE-OIL B GEAR BOX SUPPLY
1779M34G01	CF6-80E	TUBE-DRAIN ACCESSORY

PART #	ENG #	NOMENCLATURE
1779M34G01	CF6-80E	TUBE-DRAIN ACCESSORY
1779M34G02	CF6-80E	TUBE-DRAIN ACCESSORY
1779M34G02	CF6-80E	TUBE-DRAIN ACCESSORY
1779M64G01	CF6-80E	TUBE-HMU FUEL DR
1779M64G01	CF6-80E	TUBE-HMU FUEL DR
1779M64G01	CF6-80E	TUBE-HMU FUEL DR
1779M64G01	CF6-80E	TUBE-HMU FUEL DR
1779M74G01	CF6-80E	MANIFOLD-DRAIN FUEL ACTUATOR BOTTOM
1779M74G01	CF6-80E	MANIFOLD-DRAIN FUEL ACTUATOR BOTTOM
1779M76G01	CF6-80E	MANIFOLD-DRAIN FUEL ACTUATOR LEFT SIDE
1779M76G01	CF6-80E	MANIFOLD-DRAIN FUEL ACTUATOR LEFT SIDE
1779M85G01	CF6-80E	TUBE-OIL, LUBE AND SCAV PMP TO SERVO FUEL HTR
1779M85G01	CF6-80E	TUBE, OIL-LUBE AND SCAV PMP TO HEAT EXCHNGR, FWD
1780M20G01	CF6-80E	TUBE-AIR PSI2
1780M20G01	CF6-80E	TUBE-AIR PSI2
1780M20G02	CF6-80E	TUBE-AIR PSI2
1780M20G02	CF6-80E	TUBE-AIR PSI2
1780M32G01	CF6-80E	TUBE-OIL
1780M34G01	CF6-80E	TUBE-OIL
1789M31G01	CF6-80E	TUBE-OIL/IDG AGB PAD
1789M31G01	CF6-80E	TUBE-OIL/IDG AGB PAD
1789M36G01	CF6-80E	TUBE-DRAIN BOX
1789M36G01	CF6-80E	TUBE-DRAIN BOX JUNCTION UPPER
1789M46G01	CF6-80E	TUBE-FUEL JUMPER
1789M46G01	CF6-80E	TUBE-FUEL JUMPER
1789M91G01	CF6-80E	TUBE-FLUID SCUP DR
1789M91G01	CF6-80E	TUBE-FLUID SCUP DR
1789M93G01	CF6-80E	TUBE-HMU DR
1789M93G01	CF6-80E	TUBE-HMU DR
1789M93G01	CF6-80E	TUBE-HMU DR
1789M93G01	CF6-80E	TUBE-HMU DR
1789M95G01	CF6-80E	TUBE-PYLON DR
1789M95G01	CF6-80E	TUBE-PYLON DR
1790M26G01	CF6-80E	TUBE-FUEL JUMPER
1790M26G01	CF6-80E	TUBE-FUEL JUMPER
1790M33P01	CF6-80E	TUBE-FUEL SUPPLY
1790M33P01	CF6-80E	TUBE-FUEL SUPPLY
1790M33P02	CF6-80E	TUBE-FUEL HOSE
1790M33P02	CF6-80E	TUBE-FUEL HOSE
1790M33P03	CF6-80E	TUBE-FUEL SUPPLY

PART #	ENG #	NOMENCLATURE
1790M33P03	CF6-80E	TUBE-FUEL SUPPLY
1790M33P04	CF6-80E	TUBE-FUEL HOSE
1790M33P04	CF6-80E	TUBE-FUEL HOSE
1790M33P05	CF6-80E	TUBE-FUEL SUPPLY
1790M33P05	CF6-80E	TUBE-FUEL SUPPLY
1790M33P06	CF6-80E	TUBE-FUEL HOSE
1790M33P06	CF6-80E	TUBE-FUEL HOSE
1790M33P07	CF6-80E	TUBE-FUEL SUPPLY
1790M33P07	CF6-80E	TUBE-FUEL SUPPLY
1790M33P08	CF6-80E	TUBE-FUEL HOSE
1790M33P08	CF6-80E	TUBE-FUEL HOSE
1790M92P01	CF6-80E	TUBE AND HOSE-FUEL
1790M92P01	CF6-80E	TUBE AND HOSE-FUEL
1790M92P02	CF6-80E	TUBE AND HOSE-FUEL
1790M92P02	CF6-80E	TUBE AND HOSE-FUEL
1790M92P03	CF6-80E	TUBE AND HOSE-FUEL
1790M92P03	CF6-80E	TUBE AND HOSE-FUEL
1790M92P04	CF6-80E	TUBE AND HOSE-FUEL
1790M92P04	CF6-80E	TUBE AND HOSE-FUEL
1791M19G01	CF6-80E	TUBE-DRAIN PYLON
1791M19G01	CF6-80E	TUBE-DRAIN PYLON
1791M31G01	CF6-80E	DUCT-AIR HPT ACC
1791M31G01	CF6-80E	DUCT-AIR HPT ACC
1791M36G01	CF6-80E	TUBE-AIR, PS14
1791M55G02	CF6-80E	MANIFOLD-PRESSURE SENSING PS3 P25 P49
1791M55G02	CF6-80E	MANIFOLD-PRESSURE SENSING PS3 P25 P49
1791M72P01	CF6-80E	HOSE-FUEL HMU TO
1791M72P01	CF6-80E	HOSE-FUEL HMU TO FUEL/OIL COOLER
1791M72P02	CF6-80E	HOSE-FUEL HMU TO
1791M72P02	CF6-80E	HOSE-FUEL HMU TO FUEL/OIL COOLER
1791M72P03	CF6-80E	HOSE-FUEL HMU TO
1791M72P03	CF6-80E	HOSE-FUEL HMU TO FUEL/OIL COOLER
1791M72P04	CF6-80E	HOSE-FUEL HMU TO
1791M72P04	CF6-80E	HOSE-FUEL HMU TO FUEL/OIL COOLER
1791M83G01	CF6-80E	TUBE-P25 AIR
1797M15G01	CF6-80E	TUBE-OIL SUPPLY
1797M87G01	CF6-80E	TUBE-OIL SUPPLY
1802M16G01	CF6-80E	TUBE-AIR 7TH STAGE
1802M16G02	CF6-80E	TUBE-AIR 7TH STAGE
1802M18G01	CF6-80E	TUBE-PRESS AIR 7TH

PART #	ENG #	NOMENCLATURE
1802M72G01	CF6-80E	TUBE-FUEL DR
1802M72G01	CF6-80E	TUBE-FUEL DR
1802M72G01	CF6-80E	TUBE-FUEL DR
1802M72G01	CF6-80E	TUBE-FUEL DR
1802M88G01	CF6-80E	MANIFOLD-OIL LUBE SPLY
1802M88G01	CF6-80E	MANIFOLD-OIL LUBE SPLY
1802M91G01	CF6-80E	TUBE-OIL D SUMP SPLY
1802M91G01	CF6-80E	TUBE-OIL D SUMP SPLY
1802M98G01	CF6-80E	TUBE-AIR, CORE COWL COOLING
1802M98G01	CF6-80E	TUBE-AIR, CORE COWL COOLING
1803M22G01	CF6-80E	TUBE-AIR, B SUMP VENT
1803M22G01	CF6-80E	TUBE-AIR, B SUMP VENT
1803M24G01	CF6-80E	TUBE-AIR COMPARTMENT COOLING CONTROL VALVE
1803M31P01	CF6-80E	TUBE AND HOSE-OIL IDG
1803M31P01	CF6-80E	TUBE AND HOSE-OIL IDG
1803M31P02	CF6-80E	TUBE
1803M31P02	CF6-80E	TUBE
1803M31P03	CF6-80E	TUBE
1803M31P03	CF6-80E	TUBE
1803M35G01	CF6-80E	MANIFOLD-OIL PRESS
1803M35G01	CF6-80E	MANIFOLD-OIL PRESS
1803M35G02	CF6-80E	MANIFOLD-OIL PRESS
1803M35G02	CF6-80E	MANIFOLD-OIL PRESS
1803M48G01	CF6-80E	TUBE-AIR PS3 FORWARD
1803M48G01	CF6-80E	TUBE-AIR PS3 FORWARD
1803M48G02	CF6-80E	TUBE-AIR PS3 FORWARD
1803M48G02	CF6-80E	TUBE-AIR PS3 FORWARD
1803M61G01	CF6-80E	TUBE-FUEL PUMP TO HMU
1803M63G01	CF6-80E	TUBE-FUEL HMU TO
1803M63G01	CF6-80E	TUBE-FUEL HMU TO FLOWMETER
1803M65G02	CF6-80E	MANIFOLD-FUEL SUPPLY
1803M65G02	CF6-80E	MANIFOLD-FUEL SUPPLY
1803M67G01	CF6-80E	TUBE-FUEL FILTER TO SERVO HEATER
1803M67G01	CF6-80E	TUBE-FUEL FILTER TO SERVO HEATER
1803M69G01	CF6-80E	TUBE-OIL, SERVO FUEL HTR REF PRESS
1803M69G01	CF6-80E	TUBE-OIL, SERVO FUEL HTR REF PRESS
1803M71G01	CF6-80E	TUBE-OIL SCAV PMP TO FUEL/OIL SERVO HTR
1803M71G01	CF6-80E	TUBE-OIL SCAV PMP TO FUEL/OIL SERVO HTR
1803M75G01	CF6-80E	TUBE-OIL, RTN
1803M75G01	CF6-80E	TUBE-OIL, RTN

PART #	ENG #	NOMENCLATURE
1803M94G01	CF6-80E	TUBE-OIL D SCAVANGE AFT
1803M94G01	CF6-80E	TUBE-OIL D SCAVANGE AFT
1803M94G02	CF6-80E	TUBE-OIL D SCAVANGE AFT
1803M94G02	CF6-80E	TUBE-OIL D SCAVANGE AFT
1803M96G01	CF6-80E	MANIFOLD-DRAIN FUEL
1803M96G01	CF6-80E	MANIFOLD-DRAIN FUEL VALVE MODULATING
1803M96G02	CF6-80E	MANIFOLD-DRAIN FUEL
1803M96G02	CF6-80E	MANIFOLD-DRAIN FUEL
1803M96G02	CF6-80E	MANIFOLD-DRAIN FUEL VALVE MODULATING
1803M96G02	CF6-80E	MANIFOLD-DRAIN FUEL VALVE MODULATING
1822M33G01	CF6-80E	MANIFOLD-OIL IN
1825M67G01	CF6-80E	DUCT-AIR INLET HPT ACC
1825M67G01	CF6-80E	DUCT-AIR INLET HPT ACC
1825M68G01	CF6-80E	TUBE-DRAIN, FUEL
1825M68G01	CF6-80E	TUBE-DRAIN, FUEL ACCESSORY
1825M83G01	CF6-80E	TUBE-AIR TURBINE COOLING
1825M83G01	CF6-80E	TUBE-AIR TURBINE COOLING
1825M84G01	CF6-80E	MANIFOLD-AIR TURBINE
1825M84G01	CF6-80E	MANIFOLD-AIR TURBINE COOLING
1825M85G01	CF6-80E	TUBE-AIR TURBINE COOLING
1825M85G01	CF6-80E	TUBE-AIR TURBINE COOLING
1826M12G01	CF6-80E	MANIFOLD-PRESSURE SENSING PS3 P25 P49
1826M12G01	CF6-80E	MANIFOLD-PRESSURE SENSING PS3 P25 P49
1826M12G02	CF6-80E	MANIFOLD-PRESSURE SENSING PS3 P25 P49
1826M12G02	CF6-80E	MANIFOLD-PRESSURE SENSING PS3 P25 P49
1826M15G01	CF6-80E	MANIFOLD-AIR HIGH PRESS
1826M15G01	CF6-80E	MANIFOLD-AIR HIGH PRESS 11TH STAGE UPPER RIGHT SIDE
1826M16G01	CF6-80E	MANIFOLD-AIR HIGH PRESS
1826M16G01	CF6-80E	MANIFOLD-AIR HIGH PRESS 11TH STAGE LOWER RIGHT SIDE
1826M17G01	CF6-80E	MANIFOLD-AIR HIGH PRESS 11TH STAGE LOWER LEFT SIDE
1826M18G01	CF6-80E	MANIFOLD-AIR HIGH PRESS
1826M18G01	CF6-80E	MANIFOLD-AIR HIGH PRESS 11TH STAGE UPPER LEFT SIDE
1826M21G01	CF6-80E	MANIFOLD-AIR LPT
1826M21G01	CF6-80E	MANIFOLD-AIR LPT COOLING L/S
1826M22G01	CF6-80E	MANIFOLD-AIR LPT
1826M22G01	CF6-80E	MANIFOLD-AIR LPT COOLING R/S
1826M46G01	CF6-80E	TUBE-AIR HPT COOLING
1826M46G01	CF6-80E	TUBE-AIR HPT COOLING
1826M46G01	CF6-80E	TUBE-AIR HPT COOLING
1826M46G01	CF6-80E	TUBE-AIR HPT COOLING

PART #	ENG #	NOMENCLATURE
1826M48G01	CF6-80E	TUBE-AIR TURBINE
1826M49G01	CF6-80E	TUBE-AIR TURBINE
1826M64G01	CF6-80E	TUBE-AIR P49
1832M15G01	CF6-80E	TUBE-OIL D SCAVENGE MID
1832M15G01	CF6-80E	TUBE-OIL D SCAVENGE MID
1832M15G02	CF6-80E	TUBE-OIL D SCAVENGE MID
1832M15G02	CF6-80E	TUBE-OIL D SCAVENGE MID
1832M23G01	CF6-80E	TUBE-AIR, P49
1832M25G01	CF6-80E	TUBE-AIR, P49
1832M27G01	CF6-80E	MANIFOLD-AIR IGNITION LEAD COOLING
1832M40G01	CF6-80E	TUBE-DRAIN VSV AND VBV
1832M40G01	CF6-80E	TUBE-DRAIN VSV AND VBV
1832M49G01	CF6-80E	TUBE-OIL, LUBE AND SCAV PMP TO SERVO FUEL HTR
1832M49G01	CF6-80E	TUBE-OIL, LUBE AND SCAV PMP TO SERVO FUEL HTR
1832M49G02	CF6-80E	TUBE-OIL, LUBE AND SCAV PMP TO SERVO FUEL HTR
1832M49G02	CF6-80E	TUBE-OIL, LUBE AND SCAV PMP TO SERVO FUEL HTR
1832M51G01	CF6-80E	TUBE-OIL C SCAV
1832M51G01	CF6-80E	TUBE-OIL C SCAV
1832M64P01	CF6-80E	TUBE-HOSE OIL
1832M64P02	CF6-80E	TUBE-HOSE OIL
1832M64P03	CF6-80E	TUBE-HOSE OIL
1832M68P01	CF6-80E	TUBE AND HOSE-FUEL VSV ACTUATOR HEAD END
1832M68P01	CF6-80E	TUBE AND HOSE-FUEL VSV ACTUATOR HEAD END
1832M68P02	CF6-80E	TUBE AND HOSE-FUEL VSV ACTUATOR HEAD END
1832M68P02	CF6-80E	TUBE AND HOSE-FUEL VSV ACTUATOR HEAD END
1832M68P03	CF6-80E	TUBE AND HOSE-FUEL VSV ACTUATOR HEAD END
1832M68P03	CF6-80E	TUBE AND HOSE-FUEL VSV ACTUATOR HEAD END
1832M68P04	CF6-80E	TUBE AND HOSE-FUEL VSV ACTUATOR HEAD END
1832M68P04	CF6-80E	TUBE AND HOSE-FUEL VSV ACTUATOR HEAD END
1832M83G01	CF6-80E	TUBE-OIL, LWR
1832M83G01	CF6-80E	TUBE-OIL, LWR
1832M87G01	CF6-80E	MANIFOLD-DRAIN,MID
1832M87G01	CF6-80E	MANIFOLD-DRAIN,MID
1833M12G01	CF6-80E	MANIFOLD-PS12
1833M12G01	CF6-80E	MANIFOLD-PS12
1833M12G02	CF6-80E	MANIFOLD-PS12
1833M12G02	CF6-80E	MANIFOLD-PS12
1833M14G01	CF6-80E	TUBE-AIR, PS12
1833M14G01	CF6-80E	TUBE-AIR, PS12
1833M14G02	CF6-80E	TUBE-AIR, PS12

PART #	ENG #	NOMENCLATURE
1833M14G02	CF6-80E	TUBE-AIR, PS12
1833M18G01	CF6-80E	TUBE-AIR, PS12
1833M18G01	CF6-80E	TUBE-AIR, PS12
1833M18G02	CF6-80E	TUBE-AIR, PS12
1833M18G02	CF6-80E	TUBE-AIR, PS12
1833M22G01	CF6-80E	TUBE-AIR, PS12
1833M22G01	CF6-80E	TUBE-AIR, PS12
1833M22G02	CF6-80E	TUBE-AIR, PS12
1833M22G02	CF6-80E	TUBE-AIR, PS12
1833M24G01	CF6-80E	TUBE-AIR, PS12
1833M24G01	CF6-80E	TUBE-AIR, PS12
1833M24G02	CF6-80E	TUBE-AIR, PS12
1833M24G02	CF6-80E	TUBE-AIR, PS12
1833M28G01	CF6-80E	TUBE-OIL SUPPLY FILTER
1833M28G01	CF6-80E	TUBE-OIL SUPPLY FILTER
1833M30G01	CF6-80E	TUBE-OIL SCAVENGE
1833M30G01	CF6-80E	TUBE-OIL SCAVENGE
1833M36G01	CF6-80E	TUBE-AIR, PS14
1833M61P01	CF6-80E	TUBE-HOSE
1833M61P01	CF6-80E	TUBE-HOSE
1833M61P02	CF6-80E	TUBE-HOSE
1833M61P02	CF6-80E	TUBE-HOSE
1833M61P03	CF6-80E	TUBE-HOSE
1833M61P03	CF6-80E	TUBE-HOSE
1833M61P04	CF6-80E	TUBE-HOSE
1833M61P04	CF6-80E	TUBE-HOSE
1833M78G01	CF6-80E	TUBE-HYDR, PWR DR OPR
1833M80G01	CF6-80E	TUBE-HYDR, PWR DR OPR
1833M82G01	CF6-80E	TUBE-HYDR, PWR DR OPR
1833M90G01	CF6-80E	TUBE-HYDR, PWR DR OPR
1833M94G02	CF6-80E	TUBE-OIL SPLY PUMP TO FLTR
1833M94G02	CF6-80E	TUBE-OIL SPLY PUMP TO FLTR
1833M94G03	CF6-80E	TUBE-OIL SPLY PUMP TO FLTR
1833M94G03	CF6-80E	TUBE-OIL SPLY PUMP TO FLTR
1848M16G01	CF6-80E	MANIFOLD-UPR OIL/HYD DR
1848M16G01	CF6-80E	MANIFOLD-UPR OIL/HYD DR
1848M31P03	CF6-80E	TUBE AND HOSE-OIL D
1848M31P03	CF6-80E	TUBE AND HOSE-OIL D
1848M56G01	CF6-80E	TUBE-OIL, SERVO FUEL HTR TO HT EXCH
1848M56G01	CF6-80E	TUBE-OIL, SERVO FUEL

PART #	ENG #	NOMENCLATURE
1848M58G01	CF6-80E	TUBE-OIL COOLER TO TANK
1848M58G01	CF6-80E	TUBE-OIL COOLER TO TANK
1848M62G01	CF6-80E	TUBE-OIL, IDG
1848M62G01	CF6-80E	TUBE-OIL, IDG
1848M68G01	CF6-80E	TUBE-LWR OIL/HYD DR
1848M68G01	CF6-80E	TUBE-LWR OIL/HYD DR
1848M85G01	CF6-80E	TUBE-FUEL
1848M86G01	CF6-80E	TUBE-FUEL LPT
1848M87G01	CF6-80E	TUBE-DRAIN, JUNCTION
1848M87G01	CF6-80E	TUBE-DRAIN, JUNCTION BOX LOWER
1849M37G01	CF6-80E	TUBE-FUEL
1849M80G01	CF6-80E	TUBE-OIL LUBE PUMP SPLINE SPLY
1849M80G01	CF6-80E	TUBE-OIL LUBE PUMP SPLINE SPLY
1849M82G01	CF6-80E	MANIFOLD-OIL PRESS TRANSMITTER
1849M82G01	CF6-80E	MANIFOLD-OIL PRESS
1849M90G01	CF6-80E	TUBE-OIL TANK
1849M90G01	CF6-80E	TUBE-OIL TANK
1849M99G01	CF6-80E	DUCT-AIR HPT CLG
1849M99G01	CF6-80E	DUCT-AIR HPT CLG
1850M14G01	CF6-80E	TUBE-OIL DRAIN SCUP UPR
1850M14G01	CF6-80E	TUBE-OIL DRAIN SCUP UPR
1850M14G01	CF6-80E	TUBE-OIL DRAIN SCUP UPR
1850M14G01	CF6-80E	TUBE-OIL DRAIN SCUP UPR
1850M16G01	CF6-80E	TUBE-OIL DRAIN SCUP
1850M16G01	CF6-80E	TUBE-OIL DRAIN SCUP
1850M16G01	CF6-80E	TUBE-OIL DRAIN SCUP
1850M16G01	CF6-80E	TUBE-OIL DRAIN SCUP
1866M19P01	CF6-80E	SLEEVE-TUBE (SPD)
1866M21P01	CF6-80E	TUBE-LP RECOUP FWD AIR
1866M21P01	CF6-80E	TUBE-LP RECOUP FWD AIR
1866M21P01	CF6-80E	TUBE-LP RECOUP FWD AIR
1872M22G03	CF6-80E	DUCT-AIR WYE
1883M41G06	CF6-80E	MANIFOLD-CLG, LPT
1883M41G06	CF6-80E	MANIFOLD-CLG LPT
1883M41G06	CF6-80E	MANIFOLD-CLG, LPT
1883M41G06	CF6-80E	MANIFOLD-CLG, LPT
1883M41G08	CF6-80E	MANIFOLD-CLG, LPT
1883M41G08	CF6-80E	MANIFOLD-CLG, LPT
1885M10G01	CF6-80E	TUBE-EXPANDABLE SEAL
1885M10G01	CF6-80E	TUBE-EXPANDABLE SEAL AIR

PART #	ENG #	NOMENCLATURE
1885M89G01	CF6-80E	TUBE-AIR SUPPLY 7TH
1885M96G01	CF6-80E	TUBE-AIR P49
1952M20G01	CF6-80E	TUBE-OIL GEARBOX
1952M20G01	CF6-80E	TUBE-OIL GEARBOX SUPPLY
1952M33G01	CF6-80E	MANIFOLD-AIR IGNITION LEAD COOLING
1952M39G01	CF6-80E	TUBE-AIR PSI2
1952M39G01	CF6-80E	TUBE-AIR PS12
1952M39G02	CF6-80E	TUBE-AIR PSI2
1952M39G02	CF6-80E	TUBE-AIR PS12
1952M47G01	CF6-80E	MANIFOLD-FUEL SUPPLY
1952M47G01	CF6-80E	MANIFOLD-FUEL SUPPLY
1952M53G01	CF6-80E	DUCT-AIR WYE
1952M56G01	CF6-80E	TUBE-SUPPLY OIL D
1952M56G01	CF6-80E	TUBE-SUPPLY OIL D
1967M33G01	CF6-80E	DUCT-AIR LP RECOUP AFT
1967M34G01	CF6-80E	TUBE-AIR, B SUMP VENT
1967M34G01	CF6-80E	TUBE-AIR, B SUMP VENT
1977M58P03	CF6-80E	HOSE-OIL
1977M58P03	CF6-80E	HOSE
1977M71G01	CF6-80E	TUBE-LP RECOUP
1977M71G01	CF6-80E	TUBE-LP RECOUP
1977M96G01	CF6-80E	MANIFOLD-HPT ACTIVE CLEARANCE CONTROL
1977M96G01	CF6-80E	MANIFOLD-HPT ACTIVE CLEARANCE CONTROL
1977M97G01	CF6-80E	MANIFOLD-AIR, HPT ACTIVE CLEARANCE CONTROL
1977M97G01	CF6-80E	MANIFOLD-AIR, HPT ACTIVE CLEARANCE CONTROL
1978M45G01	CF6-80E	MANIFOLD-HPT ACTIVE CLEARANCE CONTROL
1978M45G01	CF6-80E	MANIFOLD-HPT ACTIVE CLEARANCE CONTROL
1978M46G01	CF6-80E	MANIFOLD-HPT ACTIVE CLEARANCE CONTROL
1978M46G01	CF6-80E	MANIFOLD-HPT ACTIVE CLEARANCE CONTROL
1978M47G01	CF6-80E	MANIFOLD-HPT ACTIVE CLEARANCE CONTROL
1978M47G01	CF6-80E	MANIFOLD-HPT ACTIVE CLEARANCE CONTROL
1978M79G01	CF6-80E	DUCT-AIR INLET HPT ACC
1978M79G01	CF6-80E	DUCT-AIR INLET HPT ACC
1990M30G01	CF6-80E	TUBE-OIL 4 & 5 BRG
1990M30G01	CF6-80E	TUBE-OIL 4 & 5 BRG
1990M39G01	CF6-80E	TUBE-FUEL FILTER TO SERVO HEATER
1990M39G01	CF6-80E	TUBE-FUEL FILTER TO SERVO HEATER
1990M40P01	CF6-80E	TUBE AND HOSE-FUEL, HEAT EXCHANGER TO HMU
1990M40P01	CF6-80E	TUBE AND HOSE-FUEL, HEAT EXCHANGER TO HMU
1991M66G01	CF6-80E	MANIFOLD-FUEL SUPPLY

PART #	ENG #	NOMENCLATURE
1991M66G01	CF6-80E	MANIFOLD-FUEL SUPPLY
1991M69G01	CF6-80E	TUBE-AIR HP RECOUP SUPPLY RIGHT SIDE
1991M70G01	CF6-80E	TUBE-AIR SUPPLY HP
1991M70G01	CF6-80E	TUBE-AIR HP RECOUP UPPER
1991M70G01	CF6-80E	TUBE-AIR HP RECOUP UPPER
1991M71G01	CF6-80E	TUBE-AIR HP RECOUP
1991M71G01	CF6-80E	TUBE-AIR SUPPLY HP RECOUP LS
1991M72G01	CF6-80E	TUBE-AIR HP RECOUP LOWER
1991M72G01	CF6-80E	TUBE-AIR HP RECOUP LOWER
1996M28G01	CF6-80E	TUBE-FUEL
1996M29G01	CF6-80E	TUBE-FUEL DRAIN HPT
1996M29G01	CF6-80E	TUBE-FUEL DRAIN HPT CONTROL VALVE
1996M30G01	CF6-80E	TUBE-FUEL PMP DR
1996M30G01	CF6-80E	TUBE-FUEL PMP DR
1996M32G01	CF6-80E	TUBE-HMU FUEL DR
1996M32G01	CF6-80E	TUBE-HMU FUEL DR
1996M33G01	CF6-80E	TUBE-HMU DR
1996M33G01	CF6-80E	TUBE-HMU DR
1996M34G01	CF6-80E	TUBE-FUEL DR
1996M34G01	CF6-80E	TUBE-FUEL DR
1996M35G01	CF6-80E	MANIFOLD-DRAIN FUEL
1996M35G01	CF6-80E	MANIFOLD-DRAIN FUEL VALVE MODULATING
1996M41G01	CF6-80E	TUBE-OIL DRAIN SCUP UPR
1996M41G01	CF6-80E	TUBE-OIL DRAIN SCUP UPR
1996M42G01	CF6-80E	TUBE-OIL DRAIN SCUP
1996M42G01	CF6-80E	TUBE-OIL DRAIN SCUP
1998M11G01	CF6-80E	DUCT-AIR HPT CLG
1998M11G01	CF6-80E	DUCT-AIR HPT CLG
1998M46G01	CF6-80E	TUBE AND HOSE-FUEL, HEAT EXCHANGER TO HMU
1998M46G01	CF6-80E	TUBE AND HOSE-FUEL, HEAT EXCHANGER TO HMU
1998M47G01	CF6-80E	TUBE-SUPPLY OIL D
1998M47G01	CF6-80E	TUBE-SUPPLY OIL D
1998M47G01	CF6-80E	TUBE-SUPPLY OIL D
1998M48G01	CF6-80E	TUBE-OIL D SPLY
1998M55G01	CF6-80E	MANIFOLD-CLG,LPT
1998M55G01	CF6-80E	MANIFOLD-CLG,LPT
1998M61G01	CF6-80E	MANIFOLD-LPT INLET
2088M97G01	CF6-80E	MANIFOLD-CLG,LPT
2088M97G01	CF6-80E	MANIFOLD-CLG LPT
2088M97G01	CF6-80E	MANIFOLD-CLG,LPT

PART #	ENG #	NOMENCLATURE
2088M97G01	CF6-80E	MANIFOLD-CLG,LPT
2096M10G01	CF6-80E	MANIFOLD-CLG,LPT
2096M10G01	CF6-80E	MANIFOLD-CLG,LPT
2096M10G01	CF6-80E	MANIFOLD-CLG,LPT
2096M10G01	CF6-80E	MANIFOLD-CLG,LPT
2156M29G01	CF6-80E	MANIFOLD-AIR, HYDRAULIC DAMPENER COOLING
2156M29G01	CF6-80E	MANIFOLD-AIR, HYDRAULIC DAMPENER COOLING
2156M35G01	CF6-80E	TUBE-UNDER COWL COOLING
2156M35G01	CF6-80E	TUBE-UNDER COWL COOLING AIR
2156M56G01	CF6-80E	TUBE-AIR HPT SUPPLY
2156M56G01	CF6-80E	TUBE-AIR HPT SUPPLY
2156M82G01	CF6-80E	DUCT-AIR LPT ACC
2156M86G01	CF6-80E	MANIFOLD-DRAIN,MID
2156M86G01	CF6-80E	MANIFOLD-DRAIN,MID
2186M83G01	CF6-80E	DUCT-AIR INLET HPT ACC
2186M83G01	CF6-80E	DUCT-AIR INLET HPT ACC
2186M87G01	CF6-80E	MANIFOLD-PRESSURE SENSING PS3 P25 P49
2186M87G01	CF6-80E	MANIFOLD-PRESSURE
2186M88G01	CF6-80E	MANIFOLD-PRESSURE SENSING PS3 P25 P49
2186M88G01	CF6-80E	MANIFOLD-PRESSURE SENSING PS3 P25 P49
2192M43G01	CF6-80E	TUBE-OIL SPLY
2192M51P01	CF6-80E	TUBE AND HOSE-FUEL VBV ACTUATOR ROD END
2192M51P01	CF6-80E	TUBE AND HOSE-FUEL VBV ACTUATOR ROD END
2192M51P02	CF6-80E	TUBE AND HOSE-FUEL VBV ACTUATOR ROD END
2192M51P02	CF6-80E	TUBE AND HOSE-FUEL VBV ACTUATOR ROD END
2192M69G01	CF6-80E	TUBE AND HOSE-FUEL VBV ACTUATOR ROD END
2192M69G01	CF6-80E	TUBE AND HOSE-FUEL VBV ACTUATOR ROD END
2193M99G01	CF6-80E	TUBE-EXPANDABLE SEAL
2193M99G01	CF6-80E	TUBE-EXPANDABLE SEAL AIR
224-4101-505	CF6-80E	DUCT ASSY
224-4250-505	CF6-80E	DUCT
224-4251-505	CF6-80E	DUCT
2285M80G01	CF6-80E	TUBE-OIL
277-1115-503	CF6-80E	DUCT
277-1150-501	CF6-80E	TUBE ASSY
277-1413-501	CF6-80E	TUBE ASSY
277-1414-501	CF6-80E	TUBE ASSY-MID SPAN
277-1420-501	CF6-80E	TUBE ASSY
277-1503-503	CF6-80E	DUCT ASSY
277-1504-501	CF6-80E	DUCT ASSY

PART #	ENG #	NOMENCLATURE
277-1505-501	CF6-80E	DUCT ASSY
277-1506-501	CF6-80E	DUCT ASSY
277-1513-501	CF6-80E	TUBE ASSY
277-1523-501	CF6-80E	TUBE-EXHAUST
277-1523-503	CF6-80E	TUBE-EXHAUST
277-1526-503	CF6-80E	DUCT
277-1527-503	CF6-80E	DUCT
277-1651-503	CF6-80E	DUCT ASSY
277-1739-503	CF6-80E	TUBE ASSY
277D1580-507	CF6-80E	DUCT ASSY
87684-4	CF6-80E	MANIFOLD ASSY
87685-1	CF6-80E	MANIFOLD ASSY
87685-2	CF6-80E	MANIFOLD ASSY
87749-2	CF6-80E	DUCT ASSY
9107M15P01	CF6-80E	REDUCER-TUBE
9285M39P10	CF6-80E	HOSE-OIL
9285M39P10	CF6-80E	HOSE-OIL
9285M39P10	CF6-80E	HOSE-OIL
9285M39P10	CF6-80E	HOSE-OIL
9285M39P11	CF6-80E	HOSE-OIL
9285M39P11	CF6-80E	HOSE-OIL
9285M39P11	CF6-80E	HOSE-OIL
9285M39P11	CF6-80E	HOSE-OIL
9285M39P11	CF6-80E	HOSE-OIL
9378M73G05	CF6-80E	DUCT-AIR
9378M83G04	CF6-80E	TUBE-AIR HP RECOUP UPPER
9378M83G04	CF6-80E	TUBE-AIR HP RECOUP UPPER
9378M85G03	CF6-80E	TUBE-AIR HP RECOUP LOWER
9378M85G03	CF6-80E	TUBE-AIR HP RECOUP LOWER
9382M10G02	CF6-80E	MANIFOLD-OIL
9382M10G02	CF6-80E	MANIFOLD-OIL
9382M10G03	CF6-80E	MANIFOLD-OIL
9382M10G03	CF6-80E	MANIFOLD-OIL
9382M10G04	CF6-80E	MANIFOLD-OIL
9382M10G04	CF6-80E	MANIFOLD-OIL
9382M12G01	CF6-80E	MANIFOLD-LUBE
9382M12G01	CF6-80E	MANIFOLD-LUBE
9382M14G01	CF6-80E	MANIFOLD-LUBE FWD
9382M14G01	CF6-80E	MANIFOLD-LUBE FWD
9382M40G01	CF6-80E	MANIFOLD-OIL SPLY
9382M40G01	CF6-80E	MANIFOLD-OIL SPLY

PART #	ENG #	NOMENCLATURE
9383M87G01	CF6-80E	MANIFOLD-OIL BRG 5
9392M11G01	CF6-80E	TUBE-OIL IN
9392M11G02	CF6-80E	TUBE-OIL IN
9392M13G02	CF6-80E	MANIFOLD-OIL IN
9392M13G02	CF6-80E	MANIFOLD-OIL IN
9392M13G03	CF6-80E	MANIFOLD-OIL IN
9392M38G01	CF6-80E	TUBE-OIL SPLY
9392M38G01	CF6-80E	TUBE-OIL SPLY
AE704312-5	CF6-80E	HOSE ASSY-PUMP TO PYLON
AE709224-2	CF6-80E	HOSE
AE709225-3	CF6-80E	HOSE
AE709239-2	CF6-80E	HOSE
AE709240-2	CF6-80E	HOSE
J1274C0086AAB	CF6-80E	HOSE-TEFLON
J1274C0086AAB	CF6-80E	HOSE-TEFLON
J1274C0086BAB	CF6-80E	HOSE-TEFLON
J1274C0086BAB	CF6-80E	HOSE-TEFLON
J1274C0086CAB	CF6-80E	HOSE-TEFLON
J1274C0086CAB	CF6-80E	HOSE-TEFLON
J1274C0086DAB	CF6-80E	HOSE-TEFLON
J1274C0086DAB	CF6-80E	HOSE-TEFLON
J1274C0104AAB	CF6-80E	HOSE-TEFLON
J1274C0104BAB	CF6-80E	HOSE-TEFLON
J1274C0104CAB	CF6-80E	HOSE-TEFLON
J1274C0104DAB	CF6-80E	HOSE-TEFLON
J1274E0110AAB	CF6-80E	HOSE-TEFLON
J1274E0110AAB	CF6-80E	HOSE-TEFLON
J1274E0110BAB	CF6-80E	HOSE-TEFLON
J1274E0110BAB	CF6-80E	HOSE-TEFLON
J1274E0110CAB	CF6-80E	HOSE-TEFLON
J1274E0110CAB	CF6-80E	HOSE-TEFLON
J1274E0111AAB	CF6-80E	HOSE-TEFLON
J1274E0111BAB	CF6-80E	HOSE-TEFLON
J1274E0111BAB	CF6-80E	HOSE-TEFLON
J1274E0111BAB	CF6-80E	HOSE-TEFLON
J1274E0111CAB	CF6-80E	HOSE-TEFLON
J1274E0111CAB	CF6-80E	HOSE-TEFLON
J1274E0111DAB	CF6-80E	HOSE-TEFLON
J1274E0111DAB	CF6-80E	HOSE-TEFLON
J1275D0090AAB	CF6-80E	HOSE-TEFLON

PART #	ENG #	NOMENCLATURE
J1275D0090BAB	CF6-80E	HOSE-TEFLON
J1275D0090CAB	CF6-80E	HOSE-TEFLON
J1275D0090DAB	CF6-80E	HOSE-TEFLON
J1279B0097DAB	CF6-80E	HOSE
J1279B0097DAB	CF6-80E	HOSE
J178E0105A	CF6-80E	HOSE TEFLON MED
J178E0105A	CF6-80E	HOSE TEFLON MED
J178E0105C	CF6-80E	HOSE TEFLON MED
J178E0105C	CF6-80E	HOSE TEFLON MED
J178E0105G	CF6-80E	HOSE TEFLON MED
J178E0105G	CF6-80E	HOSE TEFLON MED
J178H0171A	CF6-80E	HOSE-TRAY DRAIN
J178H0171A	CF6-80E	HOSE-TRAY DRAIN
J178H0171B	CF6-80E	HOSE-TRAY DRAIN
J178H0171B	CF6-80E	HOSE-TRAY DRAIN
J178H0171C	CF6-80E	HOSE-TRAY DRAIN
J178H0171C	CF6-80E	HOSE-TRAY DRAIN
J179E0145D	CF6-80E	HOSE TEFLON
J179E0145D	CF6-80E	HOSE TEFLON
M37000204-0097	CF6-80E	HOSE
M37000204-0097	CF6-80E	HOSE
MIL103406003305	CF6-80E	FLEX TUBE
MS8000G105BA	CF6-80E	HOSE TEFLON MED
MS8000G145CA	CF6-80E	HOSE TEFLON
MS8000G145CA	CF6-80E	HOSE TEFLON
MS8000K135B	CF6-80E	HOSE-TEFLON
MS8000K171B	CF6-80E	HOSE-TRAY DRAIN
MS8000K171B	CF6-80E	HOSE-TRAY DRAIN
R294P04	CF6-80E	ELBOW-TUBE
R294P04	CF6-80E	ELBOW-TUBE
S41512-0135	CF6-80E	HOSE-TEFLON
S41512-0135	CF6-80E	HOSE-TEFLON
S41512-0171	CF6-80E	HOSE-TRAY DRAIN
S41512-0171	CF6-80E	HOSE-TRAY DRAIN