

PART #	ENG #	NOMENCLATURE
108280-103	CFM56-5	Hose-Assy
108280-199	CFM56-5	Hose-Assy
108280-211	CFM56-5	Hose-Assy
108280-219	CFM56-5	Hose-Assy
108280-53	CFM56-5	Hose-Assy
110551-501	CFM56-5	Tube-Assy
110560-17	CFM56-5	Hose-Assy
110560-29	CFM56-5	Hose-Assy
112441-505	CFM56-5	Hose-Assy
1154M99G01	CFM56-2B	Tube-Fuel Drain
1155M29G01	CFM56-2B	Tube-Fuel Drain
1156M48G03	CFM56-2B	Tube-Air
116854-507	CFM56-5	Tube-Assy Flex
1303M31G10	CFM56-3	Manifold-Fuel
1303M31G12	CFM56-3	Manifold-Fuel
1303M31G12	CFM56-3	Manifold-Fuel
1303M32G12	CFM56-3	Manifold-Fuel
1324M17G01	CFM56	LPT COOLING AIR
1324M17G02	CFM56	LPT COOLING AIR
1324M17G03	CFM56	LPT COOLING AIR
1324M19G01	CFM56	LPT COOLING AIR
1324M19G02	CFM56	LPT COOLING AIR
1324M19G03	CFM56	LPT COOLING AIR
1324M91G01	CFM56-5	Tube-Drain
1339M29G09	CFM56-3	Tube assy
1339M29G13	CFM56-3	Tube assy
1348M63G01	CFM56	Tube assy
1348M88G02	CFM56	Tube assy
1348M88G07	CFM56-5	Manifold-Fuel Supply
1348M88G08	CFM56-5	Manifold-Fuel Supply
1443M11G01	CFM56-3	Tube-Air Signal Start Bleed
1443M13G01	CFM56-3	Tube-Air Signal Start Bleed
1443M18G01	CFM56-3	Tube-Air Signal Start Bleed
1443M58G01	CFM56-5	Manifold-Fuel Drain
1443M72G02	CFM56	Tube assy
1443M92G01	CFM56-5	Tube-Drain
1444M22G02	CFM56-5	Tube-Fuel Supply
1444M33G01	CFM56	Tube assy
1444M33G02	CFM56-5	Tube-Drain
1444M50G11	CFM56-5	Manifold-Fuel

PART #	ENG #	NOMENCLATURE
1444M50G12	CFM56-5	Manifold-Fuel
1444M51G11	CFM56-5	Manifold-Fuel
1444M51G17	CFM56-5	Manifold-Fuel
1444M51G18	CFM56-5	Manifold-Fuel
1444M56G02	CFM56	Tube assy
1444M56G02	CFM56	Tube assy
1444M56G04	CFM56	Tube assy
1444M56G05	CFM56	Tube assy
1444M59G01	CFM56-3	Tube-Air Signal Start Bleed
14495-505	CFM56-5	Duct Assy
14495-507	CFM56-5	Duct Assy
1455M84G01	CFM56-3	Tube-Drain-Main Fuel Supply
1466M14G01	CFM56	Tube assy
1466M14G02	CFM56	Tube assy
1466M14G03	CFM56	Tube assy
1466M54G01	CFM56-3	Tube-Air Signal Start Bleed
1466M73G01	CFM56-3	Tube-Air LPT Cooling
1466M74G01	CFM56-3	Tube-Air LPT Cooling
1466M77G01	CFM56-3	Tube-Air LPT Cooling
1466M78G01	CFM56-3	Tube-Air LPT Cooling
1466M82G01	CFM56-2B	Manifold-Drain Fuel Supply
1466M83G01	CFM56-2B	Tube-Drain Fuel Supply
1466M84G01	CFM56-3	Tube-Drain Main Fuel Supply
1466M88G01	CFM56-3	Tube-Air LPT Cooling
1467M24G01	CFM56-5	Manifold-Drain
1467M30G01	CFM56-5	Manifold-Duel Drain
1523M43P01	CFM56	Tube assy
1527M67G02	CFM56-5	Manifold-Fuel
1527M69G02	CFM56	Tube assy
1527M77G02	CFM56	Tube assy
1605M10G02	CFM56-5	Tube-Air LPT Cooling
1605M14G02	CFM56-5	Tube-Air LPT Cooling
1605M38G02	CFM56-5	Tube-Air LPT Cooling
1605M63G01	CFM56-5	Tube-Air 9th Stage
1605M65G01	CFM56-5	Tube-Drain Fuel
1605M94G01	CFM56-5	Tube-Air Discharge
1616M94G01	CFM56	Tube assy
1621M50G01	CFM56-5	Manifold-Fuel Drain
1621M82G01	CFM56-5	Tube-Drain Fuel
1645M11G01	CFM56-5	Tube-Air Start Bleed

PART #	ENG #	NOMENCLATURE
1645M25G03	CFM56	Tube assy
1645M31G03	CFM56-5	Tube-Air 9th Stage
1645M43G02	CFM56-5	Tube-Air LPT Cooling
1663M15G01	CFM56-3	Tube assy
1663M17P01	CFM56	Tube assy
1668M93G01	CFM56	Tube assy
1677M12G02	CFM56-5	Manifold-Fuel
1677M33G01	CFM56-5	Manifold-Fuel Drain
1677M55G01	CFM56-5	Manifold-Fuel Dist
1677M61G01	CFM56	Tube assy
1677M83G02	CFM56-5	Tube-Air LPT Cooling
1677M89G01	CFM56	Tube assy
1677M91G01	CFM56-5	Tube-Assy
1707M15G03	CFM56-5	Tube-Assy
1787M42G01	CFM56-5	Tube-Air
1787M42G02	CFM56-5	Tube-Air
1787M67G02	CFM56-5	Manifold-Fuel
1787M69G01	CFM56-5	Manifold-Fuel
1787M75G02	CFM56-5	Manifold-Fuel
1788M24G01	CFM56-5	Tube-Air Race
1788M40G01	CFM56-5	Tube-Fuel Stage
1788M85G02	CFM56-5	Manifold-Fuel Supply
1788M97G01	CFM56-5	Tube-Air LPT Cooling
1813M33G01	CFM56-5	Tube-Air LPT Cooling
1813M50G01	CFM56-5	Tube-Fuel Drain
1813M52G01	CFM56-5	Tube-Air LPT Cooling
1813M58G02	CFM56-5	Manifold-Fuel Supply
1813M60G01	CFM56-5	Tube-Fuel
1813M94G01	CFM56-5	Tube-Fuel Stage
1813M95G01	CFM56-5	Tube-Fuel Stage
1817M38G01	CFM56-5	Tube-Fuel Drain
1817M66G01	CFM56	Tube assy
1817M67G01	CFM56-5	Tube-Assy
1817M83G01	CFM56-5	Manifold-Fuel
1817M89G01	CFM56-5	Manifold-Fuel
1867M23G01	CFM56-5	Tube-Air
1867M25G01	CFM56-5	Tube-Fuel Supply
1867M38G01	CFM56	Tube assy
1867M43G01	CFM56	Tube assy
1867M63G01	CFM56	Tube assy

PART #	ENG #	NOMENCLATURE
1867M64G01	CFM56-3	Tube-Air
1867M67G01	CFM56	Tube assy
1869M10G01	CFM56-5	Tube-Air LPT Cooling
1869M33G01	CFM56-5	Tube-Air Discharge
1869M45G01	CFM56-5	Tube-Start Discharge
1869M46G01	CFM56-5	Tube-Air LPT Cooling
1869M47G01	CFM56-5	Tube-Air LPT Cooling
1869M48G01	CFM56-5	Tube-Air LPT Cooling
1870M11G01	CFM56	Tube assy
1870M24G01	CFM56	Tube assy
1870M27G01	CFM56	Tube assy
1870M28G01	CFM56	Tube assy
1870M32G01	CFM56	Tube assy
1870M38G01	CFM56	Tube assy
1870M45G01	CFM56	Tube assy
1870M53G01	CFM56	Tube assy
1870M70G01	CFM56-7	Tube-Air LPT Cooling
1870M71G01	CFM56-7	Tube-Air LPT Cooling
1870M72G01	CFM56-7	Tube-Air LPT Cooling
1870M73G01	CFM56-7	Tube-Air LPT Cooling
1870M86G01	CFM56	Tube assy
1870M97G01	CFM56	Tube assy
1870M98G01	CFM56	Tube assy
1871M15G01	CFM56-5	Tube-Fuel Supply
1871M19G01	CFM56-5	Manifold-Fuel Supply
1871M40G01	CFM56-5	Tube-Drain
1871M46G01	CFM56-5	Tube-Start Discharge
1871M62G01	CFM56-5	Manifold-Fuel
1871M64G02	CFM56-5	Manifold-Fuel
1871M74G01	CFM56-5	Manifold-Fuel Supply
1871M83G01	CFM56-5	Manifold-Fuel
1871M87G01	CFM56-5	Tube-Air LPT Cooling
1871M92G01	CFM56-5	Manifold-Fuel
1871M93G01	CFM56-5	Manifold-Fuel
1882M60G04	CFM56	Tube assy
1882M61G04	CMF56	Tube assy
1882M62G04	CFM56	Tube assy
1882M63G04	CFM56	Tube assy
1882M76G01	CFM56	Tube assy
1882M92G01	CFM56	Tube assy

PART #	ENG #	NOMENCLATURE
1882M94G01	CFM56	Tube assy
1892M13G01	CFM56-5	Tube-Fuel Drain
1892M16G01	CFM56-5	Tube-Air LPT Cooling
1892M18G01	CFM56-5	Tube-Air LPT Cooling
1892M47G01	CFM56-5	Tube-Air LPT Cooling
1892M61G01	CFM56	Tube assy
1892M70G01	CFM56-5	Tube-Air
1892M77G01	CFM56-5	Tube-Air
1892M89G01	CFM56-5	Tube-Air LPT Cooling
1892M92G01	CFM56-5	Tube-Air
1892M95G01	CFM56-5	Manifold-Fuel Supply
1895M12G02	CFM56	Tube assy
1895M13G01	CFM56-5	Tube-Air LPT Cooling
1895M18G02	CFM56	Tube assy
1895M18G03	CFM56	Tube assy
1895M18G04	CFM56	Tube assy
1895M18G05	CFM56	Tube assy
1895M18G06	CFM56	Tube assy
1895M18G07	CFM56-2B	Tube-Air
1895M18G08	CFM56-2B	Tube-Air
1895M18G09	CFM56	Tube assy
1895M18G10	CFM56	Tube assy
1895M18G11	CFM56	Tube assy
1895M18G12	CFM56	Tube assy
1895M18G19	CFM56-2B	Manifold-Air
1895M18G20	CFM56-2B	Manifold-Air
1895M18G21	CFM56	Tube assy
1895M18G22	CFM56	Tube assy
1895M19G01	CFM56-5	Manifold-Fuel Supply
1895M35G01	CFM56-5	Tube-Air LPT Cooling
1895M44G01	CFM56	Tube assy
1895M45G01	CFM56	Tube assy
1895M50G01	CFM56-5	Tube-Air
1895M58G01	CFM56-5	Tube-Air
1895M65G01	CFM56	Tube assy
1895M80G06	CFM56-5	Manifold-Fuel
1895M81G06	CFM56-5	Manifold-Fuel
1895M81G09	CFM56-5	Manifold-Fuel
1895M82G06	CFM56-5	Manifold-Fuel
1895M83G06	CFM56-5	Manifold-Fuel

PART #	ENG #	NOMENCLATURE
1895M83G09	CFM56-5	Manifold-Fuel
1895M95G06	CFM56	Tube assy
1896M46G01	CFM56	Tube assy
1896M65G01	CFM56	Tube assy
1896M95G02	CFM56	Tube assy
1896M95G03	CFM56-2B	Tube-Air
1896M95G04	CFM56-2B	Tube-Air
1896M95G06	CFM56	Tube assy
1897M10G01	CFM56-5	Manifold-Fuel
1897M11G01	CFM56-5	Manifold-Fuel
1897M12G01	CFM56-5	Manifold-Fuel
1897M13G01	CFM56-5	Manifold-Fuel
1897M14G01	CFM56-5	Manifold-Fuel
1897M15G01	CFM56-5	Manifold-Fuel
1897M17G01	CFM56-5	Manifold-Fuel
1897M18G01	CFM56-5	Manifold-Fuel
1897M19G01	CFM56-5	Manifold-Fuel
1897M21G01	CFM56-5	Manifold-Fuel
1897M22G02	CFM56-5	Manifold-Fuel
1897M24G01	CFM56-5	Tube-5th Stage
1897M27G01	CFM56-5	Tube-Air Start Bleed
1897M28G01	CFM56-5	Tube-Air LPT Cooling
1897M39G01	CFM56-5	Tube-5th Stage
1897M51G01	CFM56-5	Tube-Air Start Bleed
1897M67G01	CFM56-5	Tube-Air LPT Cooling
1897M68G01	CFM56-5	Tube-Air LPT Cooling
1897M69G01	CFM56-5	Tube-Air LPT Cooling
1897M72G01	CFM56-5	Tube-Air LPT Cooling
1897M74G01	CFM56-5	Tube-Air LPT Cooling
1897M75G01	CFM56-5	Tube-Air
1897M76G01	CFM56-5	Tube-Air LPT Cooling
1898M20G01	CFM56	Tube assy
1898M35G01	CFM56	Tube assy
1898M58G01	CFM56	Tube assy
1958M57G01	CFM56	Tube assy
1958M58G01	CFM56	Tube assy
1958M81G01	CFM56	Tube assy
1958M82G01	CFM56	Tube assy
1958M86G01	CFM56	Tube assy
1967M33G01	CFM56	Tube assy

PART #	ENG #	NOMENCLATURE
1969M80G01	CFM56	Tube assy
1971M17G01	CFM56-5	Manifold-Fuel
1971M18G01	CFM56-5	Manifold-Fuel
1971M32G01	CFM56-3	Tube-Air Signal Start Bleed
1971M74G01	CFM56	Tube assy
2046M51G01	CFM56	Tube assy
2046M59G01	CFM56	Tube assy
2046M61G01	CFM56	Tube assy
2046M77G01	CFM56	Tube assy
2046M82G01	CFM56	Tube assy
2071M15P01	CFM56	Tube assy
2088M96G01	CFM56	Tube assy
2088M97G01	CFM56	Tube assy
2096M44G01	CFM56	Tube assy
2175M40G01	CFM56	Tube assy
2175M41G01	CFM56	Tube assy
238-0602-503	CFM56-5	Duct Assy
238-0612-503	CFM56-5	Tube-Assy
238-0701-523	CFM56-5	Tube-Assy
238-0701-525	CFM56-5	Tube-Assy
238--0701-527	CFM56-5	Tube-Assy
238-0701-529	CFM56-5	Tube-Assy
238-0801-512	CFM56-5	Tube-Assy
238-0801-513	CFM56-5	Tube-Assy
238-0801-535	CFM56-5	Tube-Assy
238-0801-539	CFM56-5	Tube-Assy
238-0801-541	CFM56-5	Tube-Assy
238-0801-543	CFM56-5	Tube-Assy
238-0801-545	CFM56-5	Tube-Assy
238-0801-547	CFM56-5	Tube-Assy
238-0801-549	CFM56-5	Tube-Assy
238-0801-551	CFM56-5	Tube-Assy
238-0801-553	CFM56-5	Tube-Assy
238-0801-557	CFM56-5	Tube-Assy Heat
238-0801-561	CFM56-5	Tube-Assy
238D0561-505	CFM56	Tube assy
238D0561-507	CFM56-5	Tube-Assy
238D0660-507	CFM56	Tube assy
301-319-722-0	CFM56	Tube assy
301-319-724-0	CFM56	Tube assy

PART #	ENG #	NOMENCLATURE
301-320-011-0	CFM56-3	Mfld Assy-Cooling Air
301-320-012-0	CFM56-3	Mlfd Assy-Cooling Air
301-320-013-0	CFM56-3	Mfld Assy-Cooling Air
301-320-109-0	CFM56-3	Mfld Assy-Cooling Air
301-320-110-0	CFM56-3	Mlfd Assy-Cooling Air
301-544-407-0	CFM56	Tube assy
301-582-805-0	CFM56-2B	Tube-Fuel Nozzle Drain
301-583-009-0	CFM56-2,-3	FLEX LINE
301-583-010-0	CRM56-2,-3	FLEX LINE
301-583-050-0	CFM56-2,-3	FLEX LINE
301-584-010-0	CFM56-2,-3	FLEX LINE
301-584-050-0	CFM56-2,-3	FLEX LINE
301-584-609-0	CFM56-2,-3	FLEX LINE
301584-650-0	CFM56-2,-3	FLEX LINE
301-585-008-0	CFM56-2B	Tube-Fuel Drain
301-585-406-0	CFM56	Tube assy
301-585-804-0	CFM56	Tube assy
301-585-806-0	CFM56	Tube assy
301-586-003-0	CFM56-2B	Tube-Fuel Drain
301-586-006-0	CFM56-2B	Tube-Fuel Drain
301-586-208-0	CFM56-2B	Tube-Drain
301-586-406-0	CFM56-2B	Tube-Assy Vent Oil
301-586-410-0	CFM56-2A	Tube-Assy Vent Oil
301-586-411-0	CFM56-2A	Tube-Assy Vent Oil
301-586-607-0	CFM56-2A	Tube-Assy Vent Oil
301-586-809-0	CFM56-2,-3	FLEX LINE
301-586-850-0	CFM56-2,-3	FLEX LINE
301-587-607-0	CFM56-2B	Tube-Supply Oil
301-587-809-0	CFM56-2B	Tube-Assy Oil
301-587-816-0	CFM56-2A	Tube-Assy Oil
301-588-406-0	CFM56-2B	Tube-Siphon Oil
301-588-408-0	CFM56-2B	Tube-Siphon Oil
301-588-808-0	CFM56-2B	Tube-Oil Rear Supply
301-588-810-0	CFM56-2A	Tube-Oil Rear Sump Supply
301-589-007-0	CFM56-2A	Tube-Oil Rear Sump Supply
301-589-204-0	CFM56-2A	Tube-Oil Rear Sump Supply
301-589-606-0	CFM56-2A	Tube-Oil Fwd Sump Scavenge
301-589-804-0	CFM56-2B	Tube-Scavenge Gearbox
301-590-002-0	CFM56-2B	Tube-Scavenge TGB
301-590-206-0	CFM56-2A	Tube-Oil Rear Sump Scavenge

PART #	ENG #	NOMENCLATURE
301-590-405-0	CFM56-2A	Tube-Oil Rear Sump Scavenge
301-590-603-0	CFM56-2B	Tube-Oil Rear
301-590-604-0	CFM56-2B	Tube-Oil Rear
301-590-806-0	CFM56-2A	Tube-Oil Aft Sump Scavenge
301-591-002-0	CFM56-2B	Tube-Return MDL Exchange
301-591-210-0	CFM56-2B	Tube-Return Fuel Oil
301-591-218-0	CFM56-2A	Tube-Return Fuel Oil
301-591-250-0	CFM56-2A	Tube-Return Fuel Oil
301-591-904-0	CFM56-2A	Tube-Oil Rear Sump Supply
305-003-310-0	CFM56-2A	Tube-Assy
305-012-505-0	CFM56-2B	Tube-Assy
305-012-508-0	CFM56-2A	Tube-Assy
305-012-509-0	CFM56-2B	Tube-Assy
305-012-510-0	CFM56-2B	Hose-Oil Supply
305-012-511-0	CFM56-2A	Tube-Oil Supply
305-012-550-0	CFM56-2B	Hose-Oil Supply
305-050-901-0	CFM56-3	Tube Oil
305-050-906-0	CFM56-3	Tube Oil
305-050-907-0	CFM56-3	Tube Oil
305-050-907-0	CFM56	Tube assy
305-053-205-0	CFM56-2B	Tube-Drain
305-090-905-0	CFM56-2A	Tube-Oil Aft Sump Scavenge
305-090-906-0	CFM56-2B	Tube-Oil Rear
305-099-707-0	CFM56	Tube assy
305-322-001-0	CFM56-2B	Tube-Suction TGB
305-336-401-0	CFM56-2,-3	FLEX LINE
305-336-450-0	CFM56-2,-3	FLEX LINE
305-366-401-0	CFM56	FLEX LINE
305-369-506-0	CFM56	DUCT ASSY
305-397-203-0	CFM56	Tube assy
305-397-601-0	CFM56-2B	Tube-Seal Drain
305-397-602-0	CFM56-2A	Tube-Seal Drain
305-397-604-0	CFM56-2A	Tube-Seal Drain
305-397-605-0	CFM56-2A	Tube-Seal Drain
305-408-301-0	CFM56	Tube assy
305-429-602-0	CFM56-3	Tube Assy-Clg Turb
305-429-603-0	CFM56-3	Tube Assy-Clg Turb
305-429-702-0	CFM56-3	Tube Assy-Clg Turb
305-429-703-0	CFM56-3	Tube Assy-Clg Turb
305-429-803-0	CFM56-3	Tube Assy-Clg Tube

PART #	ENG #	NOMENCLATURE
305-429-804-0	CFM56-3	Tube Assy-Clg Tube
305-429-902-0	CFM56-3	Tube Assy-Clg Tube
305-429-903-0	CFM56-3	Tube Assy-Clg Tube
305-430-502-0	CFM56-3	Tube assy
305-430-503-0	CFM56-3	Tube assy
305-430-802-0	CFM56-3	Tube assy
305-430-803-0	CFM56-3	Tube assy
305-430-902-0	CFM56-3	Tube assy
305-430-903-0	CFM56-3	Tube assy
305-431-002-0	CFM56-3	Tube assy
305-431-003-0	CFM56-3	Tube assy
305-431-102-0	CFM56-3	Tube assy
305-431-103-0	CFM56-3	Tube assy
305-431-203-0	CFM56-3	Tube assy
305-431-204-0	CFM56-3	Tube assy
305-431-205-0	CFM56-3	Tube assy
305-431-303-0	CFM56-3	Tube assy
305-431-304-0	CFM56-3	Tube assy
305-431-305-0	CFM56-3	Tube assy
305-431-403-0	CFM56-3	Tube assy
305-431-404-0	CFM56-3	Tube assy
305-431-405-0	CFM56-3	Tube assy
305-431-503-0	CFM56-3	Tube assy
305-431-504-0	CFM56-3	Tube assy
305-431-505-0	CFM56-3	Tube assy
305-431-603-0	CFM56-3	Tube assy
305-431-604-0	CFM56-3	Tube assy
305-431-605-0	CFM56-3	Tube assy
305-431-803-0	CFM56-3	Tube assy
305-431-804-0	CFM56-3	Tube assy
305-431-903-0	CFM56-3	Tube assy
305-431-904-0	CFM56-3	Tube assy
305-723-200-0	CFM56	Tube assy
305-816-804-0	CFM56-2A	Tube-Return Fuel Oil
305-817-404-0	CFM56-2A	Tube-Assy Vent Oil
305-817-450-0	CFM56-2A	Tube-Assy Vent Oil
305-821-106-0	CFM56-2A	Tube-Assy Oil
305-821-107-0	CFM56-2A	Tube-Assy Oil
305-821-602-0	CFM56-2A	Tube-Anti Siphon
305-821-603-0	CFM56-2A	Tube-Anti Siphon

PART #	ENG #	NOMENCLATURE
305-822-601-0	CFM56-2B	Tube-Fuel Drain
305-824-501-0	CFM56-2A	Tube-Assy Oil
305-824-550-0	CFM56-2A	Tube-Assy Oil
305-980-005-6	CFM56	Tube assy
305-985-004-0	CFM56-3	Tube Assy-Air Cooling Upper Half
305-985-005-0	CFM56-3	Tube Assy-Air Cooling Upper Half
305-985-008-0	CFM56-3	Tube Assy-Air Cooling Upper Half
305-985-104-0	CFM56-3	Tube Assy Air Cooling-Lower Half
305-985-106-0	CFM56-3	Tube Assy Air Cooling-Lower Half
305-985-402-0	CFM56-3	Mfld-Clg Upper Half
305-985-403-0	CFM56-3	Mfld-Clg Upper Half
305-985-502-0	CFM56-3	Mfld Cooling-Lower Half
305-985-503-0	CFM56-3	Mfld Cooling-Lower Half
332A1200-1	CFM56	Tube assy
332A1301-1	CFM56	Tube assy
332A1303-16	CFM56	Tube assy
332A1304-23	CFM56	Tube assy
332A1304-24	CFM56	Tube assy
332A1305-9	CFM56	Tube assy
332A1306-1	CFM56	Tube assy
332A1308-7	CFM56	Tube assy
332A1311-20	CFM56	Tube assy
332A1311-30	CFM56	Tube assy
332A1312-9	CFM56	Tube assy
332A1313-1	CFM56	Tube assy
332A1314-19	CFM56	Tube assy
332A1320-1	CFM56	Tube assy
332A1327-5	CFM56	Tube assy
332A2310-1	CFM56	Tube assy
334-007-382-0	CFM56	Tube assy
335-008-601-0	CFM56	Tube assy
335-008-602-0	CFM56	DUCT ASSY
335-010-601-0	CFM56	Tube assy
335-010-801-0	CFM56	Tube assy
335-016-301-0	CFM56	DUCT ASSY
335-039-101-0	CFM56	Tube assy
335-065-402-0	CFM56	FLEX LINE
335-065-403-0	CFM56	FLEX LINE
335-066-701-0	CFM56-3	Tube-Seal Drain Overboard
335-104-303-0	CFM56-3	Tube Oil

PART #	ENG #	NOMENCLATURE
335-104-305-0	CFM56-3	Tube Oil
335-104-308-0	CFM56-3	Tube Oil
335-181-201-0	CFM56-3	Tube-Fuel Noz Supply Assy
335-203-801-0	CFM56-3	Tube-TC1 Shunt
335-203-850-0	CFM56-3	Tube-TC1 Shunt
335-204-001-0	CFM56-3	Tube, PBP
335-204-002-0	CFM56-3	Tube, PBP
335-204-201-0	CFM56-3	Tube, PBP
335-204-401-0	CFM56-3	Tube, PC
335-204-601-0	CFM56-3	Tube-PC
335-204-603-0	CFM56-3	Tube-PC
335-204-801-0	CFM56-3	Tube, TC3
335-205-001-0	CFM56-3	Tube-TC3
335-205-201-0	CFM56-3	Tube-TC2
335-205-401-0	CFM56-3	Hose, Rear Sump Scavenge
335-205-402-0	CFM56-3	Tube-TC2
335-205-450-0	CFM56-3	Hose, Rear Sump Scavenge
335-205-601-0	CFM56-3	Tube-TC1
335-206-201-0	CFM56-3	Tube-TS5
335-206-401-0	CFM56-3	Tube-TS9
335-206-601-0	CFM56-3	Tube-PB
335-208-805-0	CFM56	Tube assy
335-214-901-0	CFM56-3	Tube-TC1 Shunt
335-214-902-0	CFM56-3	Tube-TC1 Shunt
335-215-101-0	CFM56-3	Tube-TC2
335-216-301-0	CFM56-3	Tube-Fuel Supply Assy
335-216-302-0	CFM56-3	Tube-Fuel Supply Assy
335-216-401-0	CFM56-3	Tube-Fuel Noz Supply Assy
335-216-402-0	CFM56-3	Tube-Fuel Noz Supply Assy
335-216-403-0	CFM56-3	Tube-Fuel Noz Supply Assy
335-221-702-0	CFM56-3	Tube-Stg 5 Bleed
335-221-903-0	CFM56-3	Tube-Stg 5 Bleed
335-224-002-0	CFM56-3	Tube-Stg 5 Bleed
335-224-301-0	CFM56-3	Hose-Oil Front Brg Supply
335-224-350-0	CFM56-3	Hose-Oil Front Brg Supply
335-224-505-0	CFM56	Tube assy
335-225-804-0	CFM56	Tube assy
335-227-602-0	CFM56-3	Hose-Oil Tank Overflow
335-227-650-0	CFM56-3	Hose-Oil Tank Overflow
335-227-802-0	CFM56-3	Tube-Oil Filling

PART #	ENG #	NOMENCLATURE
335-237-501-0	CFM56	Tube assy
335-242-407-0	CFM56-3	Tube-Fuel Return
335-249-001-0	CFM56-3	Hose-Fuel Actuator Return
335-249-050-0	CFM56-3	Hose-Fuel Actuator Return
335-250-208-0	CFM56-3	Tube-CIT Sensor Supply
335-250-211-0	CFM56-3	Tube-CIT Sensor Supply
335-250-406-0	CFM56-3	Tube-CIT Sensor Supply
335-250-407-0	CFM56-3	Tube-CIT Sensor Supply
335-251-002-0	CFM56-3	Tube-Close VSV
335-251-003-0	CFM56-3	Tube-Close VSV
335-251-005-0	CFM56-3	Tube-Close VSV
335-251-203-0	CFM56-3	Tube-Air CBP
335-251-204-0	CFM56-3	Tube-Air CBP
335-251-602-0	CFM56-3	Tube-Fuel VBV Supply
335-251-603-0	CFM56-3	Tube-Fuel VBV Supply
335-251-803-0	CFM56-3	Tube-Fuel VBV Supply
335-251-805-0	CFM56-3	Tube-Fuel VBV Supply
335-251-809-0	CFM56-3	Tube-Fuel VBV Supply
335-251-851-0	CFM56-3	Tube-Fuel VBV Supply
335-252-404-0	CFM56-3	Tube-Fuel Return
335-252-405-0	CFM56-3	Tube-Fuel Return
335-252-407-0	CFM56-3	Tube-Fuel Return
335-252-604-0	CFM56-3	Tube-Fuel Stg 5 BL V
335-252-605-0	CFM56-3	Tube-Fuel Stg 5 BL V
335-252-804-0	CFM56-3	Tube-Fuel Stg 9 BL V
335-252-805-0	CFM56-3	Tube-Fuel Stg 9 BL V
335-252-806-0	CFM56-3	Tube-Fuel Stg 9 BL V
335-253-003-0	CFM56-3	Tube-Fuel VBV Supply
335-253-005-0	CFM56-3	Tube-Fuel VBV Supply
335-253-403-0	CFM56-3	Tube-Air PS3 Supply
335-253-404-0	CFM56-3	Tube-Air PS3 Supply
335-254-603-0	CFM56-3	Tube, Oil Aft Sump Supply
335-254-803-0	CFM56-3	Tube-Oil Aft Sump Scavenge
335-255-201-0	CFM56-3	Hose-Oil Rear Sump
335-255-203-0	CFM56-3	Hose-Oil Rear Sump
335-255-250-0	CFM56-3	Hose-Oil Rear Sump
335-255-251-0	CFM56-3	Hose-Oil Rear Sump
335-255-401-0	CFM56-3	Hose-Rear Sump Scavenge
335-255-404-0	CFM56-3	Hose, Rear Sump Scavenge
335-255-450-0	CFM56-3	Hose-Rear Sump Scavenge

PART #	ENG #	NOMENCLATURE
335-255-451-0	CFM56-3	Hose, Rear Sump Scavenge
335-255-452-0	CFM56-3	Hose, Rear Sump Scavenge
335-255-801-0	CFM56-3	Hose-Front Bearing Return
335-255-804-0	CFM56-3	Hose-Front Bearing Return
335-255-840-0	CFM56-3	Hose-Front Bearing Return
335-255-850-0	CFM56-3	Hose-Front Bearing Return
335-255-851-0	CFM56-3	Hose-Front Bearing Return
335-256-004-0	CFM56-3	Tube-Assy Oil
335-256-005-0	CFM56-3	Tube-Assy Oil
335-256-203-0	CFM56-3	Tube-Anti Siphon
335-256-204-0	CFM56-3	Tube-Anti Siphon
335-256-402-0	CFM56	Tube assy
335-256-601-0	CFM56-3	Tube Assy-Air PS 12
335-257-001-0	CFM56	Tube assy
335-257-601-0	CFM56-3	Tube-Oil Suction Tank
335-257-602-0	CFM56-3	Tube-Oil Suction Tank
335-257-650-0	CFM56-3	Tube-Oil Suction Tank
335-257-651-0	CFM56-3	Tube-Oil Suction Tank
335-257-652-0	CFM56-3	Tube-Oil Suction Tank
335-257-805-0	CFM56-3	Tube-Oil Tank Return
335-257-808-0	CFM56-3	Tube-Oil Tank Return
335-258-001-0	CFM56-3	Tube-Air IGN
335-258-002-0	CFM56-3	Tube-Air IGN
335-261-500-0	CFM56-3	Tube-Air PS3 Supply
335-261-550-0	CFM56-3	Tube-Air PS3 Supply
335-261-551-0	CFM56-3	Tube-Air PS3 Supply
335-263-201-0	CFM56-3	Tube, Fuel VBV Drain
335-263-202-0	CFM56-3	Tube, Fuel VBV Drain
335-263-506-0	CFM56-3	Tube-Fuel Supply Assy
335-263-507-0	CFM56-3	Tube-Fuel Supply Assy
335-263-508-0	CFM56-3	Tube-Fuel Supply Assy
335-263-510-0	CFM56-3	Tube-Fuel Supply Assy
335-263-552-0	CFM56-3	Tube-Fuel Supply Assy
335-263-553-0	CFM56-3	Tube-Fuel Supply Assy
335-263-554-0	CFM56-3	Tube-Fuel Supply Assy
335-263-555-0	CFM56-3	Tube-Fuel Supply Assy
335-263-602-0	CFM56-3	Tube-Oil Rear Sump Scavenge
335-263-801-0	CFM56	FLEX LINE
335-263-802-0	CFM56-3	Tube,Oil Rear Sump Supply
335-263-803-0	CFM56-3	Tube,Oil Rear Sump Supply

PART #	ENG #	NOMENCLATURE
335-264-007-0	CFM56-3	Tube-Fuel Noz Supply Assy
335-264-009-0	CFM56-3	Tube-Fuel Noz Supply Assy
335-264-011-0	CFM56-3	Tube-Fuel Noz Supply Assy
335-264-015-0	CFM56-3	Tube-Fuel No. 2 Supply Assy
335-264-300-0	CFM56-3	Hose-Fuel Close
335-264-350-0	CFM56-3	Hose-Fuel Close
335-264-801-0	CFM56-3	Hose-Fuel Stg 9 Blv
335-264-802-0	CFM56	FLEX LINE
335-264-850-0	CFM56-3	Hose-Fuel Stg 9 BL V
335-264-901-0	CFM56-3	Hose-Fuel Stg 5 BL V
335-264-950-0	CFM56-3	Hose-Fuel Stg 5 BL V
335-265-000-0	CFM56-3	Hose-CIT Sensor Supply
335-265-100-0	CFM56-3	Hose-CIT Sensor Supply
335-265-102-0	CFM56-3	Hose-CIT Sensor Supply
335-265-150-0	CFM56-3	Hose-CIT Sensor Supply
335-265-151-0	CFM56-3	Hose-CIT Sensor Supply
335-265-600-0	CFM56-3	Hose-Fuel Open
335-265-650-0	CFM56-3	Hose-Fuel Open
335-266-002-0	CFM56-3	Tube-Anti Siphon
335-266-200-0	CFM56-3	Tube-Air CBP
335-266-250-0	CFM56-3	Tube-Air CBP
335-266-300-0	CFM56-3	Hose-Oil Discharge Heat
335-266-302-0	CFM56-3	Hose-Oil Discharge Heat
335-266-303-0	CFM56-3	Hose-Oil Discharge Heat
335-266-350-0	CFM56-3	Hose-Oil Discharge Heat
335-266-351-0	CFM56-3	Hose-Oil Discharge Heat
335-266-352-0	CFM56-3	Hose-Oil Discharge Heat
335-266-353-0	CFM56-3	Hose-Oil Discharge Heat
335-266-400-0	CFM56-3	Tube-Fuel Return Supply
335-266-405-0	CFM56-3	Tube-Fuel Return Supply
335-266-605-0	CFM56-3	Tube-Oil Heat Exch Return
335-266-800-0	CFM56-3	Tube-Oil Disch Lubr
335-267-002-0	CFM56-3	Tube-Fuel Supply
335-267-003-0	CFM56	Tube assy
335-267-200-0	CFM56-3	Tube-Oil Suction
335-267-400-0	CFM56-3	Tube-Oil Supply Gearbox
335-267-501-0	CFM56	Tube assy
335-267-650-0	CFM56-3	Tube-Oil Suction Tank
335-267-806-0	CFM56-3	Hose-Oil Tgb Scavenger
335-267-807-0	CFM56-3	Hose-Oil Tgb Scavenger

PART #	ENG #	NOMENCLATURE
335-267-808-0	CFM56-3	Hose-Oil Tgb Scavenger
335-267-809-0	CFM56-3	Hose-Oil Tgb Scavenger
335-267-852-0	CFM56-3	Hose-Oil Tgb Scavenger
335-267-853-0	CFM56-3	Hose-Oil Tgb Scavenger
335-268-001-0	CFM56-3	Tube-Oil Pressure Tank Cover
335-268-404-0	CFM56-3	Tube, Oil Supply Tgb
335-268-550-0	CFM56-3	Hose-Oil Tank Return
335-268-600-0	CFM56-3	Hose-Oil Tank Return
335-268-601-0	CFM56-3	Hose-Oil Tank Return
335-268-650-0	CFM56-3	Hose-Oil Tank Return
335-268-651-0	CFM56-3	Hose-Oil Tank Return
335-268-652-0	CFM56-3	Hose-Oil Tank Return
335-268-801-0	CFM56-3	Hose-Nonmetallic PS12
335-268-850-0	CFM56-3	Hose-Nonmetallic PS12
335-268-900-0	CFM56-3	Hose-Oil Tank Overflow
335-268-950-0	CFM56-3	Hose-Oil Tank Overflow
335-271-601-0	CFM56-3	Tube-Oil Filling
335-271-650-0	CFM56-3	Tube-Oil Filling
335-276-003-0	CFM56-3	Tube-Fuel Stg 5 BL V
335-276-203-0	CFM56-3	Tube-Fuel Stg 9 BI V
335-282-001-0	CFM56-3	Tube-Overflow
335-282-002-0	CFM56-3	Tube-Overflow
335-282-003-0	CFM56-3	Tube-Overflow
335-282-201-0	CFM56-3	Tube-Oil Rear Sump
335-286-601-0	CFM56-3	Tube-Fuel P7
335-293-801-0	CFM56-3	Tube-PB
335-430-063-0	CFM56-3	Hose-Fuel Close
335-430-083-0	CFM56-3	Hose-Fuel Close
336-063-001-0	CFM56-5	Duct-Air
336-065-402-0	CFM56	Tube assy
336-065-403-0	CFM56	Tube assy
336-066-402-0	CFM56	FLEX LINE
336-066-403-0	CFM56	FLEX LINE
336-066-502-0	CFM56	FLEX LINE
336-066-503-0	CFM56	FLEX LINE
336-098-601-0	CFM56	Tube assy
336-143-351-0	CFM56-5	FLEX LINE
336-401-402-0	CFM56	Tube assy
336-413-301-0	CFM56-5	FLEX LINE
336-413-351-0	CFM56	FLEX LINE

PART #	ENG #	NOMENCLATURE
336-450-208-0	CFM56-5	Tube-Fuel Supply
336-450-406-0	CFM56	Tube assy
336-450-807-0	CFM56	Tube assy
336-451-005-0	CFM56	Tube assy
336-451-205-0	CFM56	Tube assy
336-452-005-0	CFM56	Tube assy
336-452-204-0	CFM56	Tube assy
336-452-605-0	CFM56	Tube assy
336-455-602-0	CFM56	Tube assy
336-458-608-0	CFM56	Tube assy
336-460-007-0	CFM56	FLEX LINE
336-460-008-0	CFM56-5	Hose-Fuel Supply
336-460-071-0	CFM56-5	Hose-Fuel Supply
336-462-002-0	CFM56-5	Hose-Oil Scavenger
336-462-003-0	CFM56-5	Hose-Oil Scavenger
336-462-051-0	CFM56-5	Hose-Oil Scavenger
336-462-052-0	CFM56-5	Hose-Oil Scavenger
336-462-071-0	CFM56-5	Hose-Oil Scavenger
336-462-102-0	CFM56	Tube assy
336-463-209-0	CFM56	Tube assy
336-463-406-0	CFM56	FLEX LINE
336-489-402-0	CFM56	Tube assy
336-504-602-0	CFM56-5	LPT ACCESSORY TUBE ASSY
336-517-004-0	CFM56	Tube assy
337-026-804-0	CFM56	Tube assy
337-027-203-0	CFM56	Tube assy
337-029-705-0	CFM56-5	Tube-Oil Rear Supply
337-029-902-0	CFM56-5	Tube-Oil Supply
337-031-704-0	CFM56	Tube assy
337-044-203-0	CFM56	Tube assy
337-099-110-0	CFM56	Tube assy
337-110-305-0	CFM56	Tube assy
337-152-702-0	CFM56-5	Tube-Oil Supply
337-153-101-0	CFM56-5	Tube-Fuel
337-154-101-0	CFM56-5	Tube-Fuel
337-176-001-0	CFM56	Tube assy
338-012-303-0	CFM56-5	Tube-Supply
338-015-604-0	CFM56-5	Tube-Assy
338-015-803-0	CFM56-5	Tube-Assy
338-019-703-0	CFM56-5	Tube-Assy

PART #	ENG #	NOMENCLATURE
338-026-607-0	CFM56-5	Tube-Oil Heater
338-037-202-0	CFM56	Tube assy
338-037-207-0	CFM56-5	Tube-Oil
338-039-603-0	CFM56	Tube assy
338-040-702-0	CFM56-5	Tube-Assy
338-040-751-0	CFM56-5	Tube-Assy
338-040-752-0	CFM56-5	Tube-Assy
338-047-002-0	CFM56-5	Tube-Assy
338-047-602-0	CFM56-5	Tube-Fuel
338-047-802-0	CFM56-5	Tube-Fuel
338-048-802-0	CFM56-5	Tube-Oil Supply
338-049-402-0	CFM56-5	Tube-Fuel Supply
338-049-602-0	CFM56-5	Tube-Fuel
338-049-802-0	CFM56-5	Tube-Fuel
338-051-401-0	CFM56	Tube assy
338-051-410-0	CFM56	Tube assy
338-052-103-0	CFM56-5	Hose-Fuel
338-052-153-0	CFM56-5	Hose-Fuel
338-052-202-0	CFM56-5	Tube-Oil Supply
338-052-203-0	CFM56-5	Tube-Oil Supply
338-052-602-0	CFM56-5	Tube-Oil Supply
338-056-502-0	CFM56-5	Tube-Fuel
338-057-751-0	CFM56	Tube assy
338-061-302-0	CFM56	Tube assy
338-061-352-0	CFM56	Tube assy
338-062-701-0	CFM56	Tube assy
338-067-703-0	CFM56	Tube assy
338-067-704-0	CFM56	Tube assy
338-075-402-0	CFM56	Tube assy
338-082-101-0	CFM56	Tube assy
338-118-602-0	CFM56	Tube assy
338-126-004-0	CFM56-5	Tube-Fuel
338-126-103-0	CFM56-5	Hose-Fuel Tube
338-126-153-0	CFM56-5	Hose-Fuel Tube
338-128-501-0	CFM56-5	Hose-Flexible
338-129-201-0	CFM56-5	Hose-Return Heater
338-129-251-0	CFM56-5	Hose-Return Heater
338-129-301-0	CFM56-5	Hose-Oil Heater
338-154-101-0	CFM56-5	Tube-Drain
338-163-304-0	CFM56-5	Tube-AFT

PART #	ENG #	NOMENCLATURE
338-166-604-0	CFM56-5	Tube-Assy
338-166-804-0	CFM56-5	Tube-Assy
338-166-904-0	CFM56-5	Tube-AFT
338-169-302-0	CFM56-5	Tube-AFT
338-171-501-0	CFM56	Tube assy
340-007-005-0	CFM56	Tube assy
340-007-102-0	CFM56	Tube assy
340-007-203-0	CFM56	Tube assy
340-008-504-0	CFM56	Tube assy
340-009-303-0	CFM56	Tube assy
340-009-401-0	CFM56	Tube assy
340-010-201-0	CFM56	Tube assy
340-010-402-0	CFM56	Tube assy
340-011-001-0	CFM56	Tube assy
340-012-802-0	CFM56	Tube assy
340-014-406-0	CFM56	Tube assy
340-015-956-0	CFM56	Tube assy
340-016-151-0	CFM56	Tube assy
340-016-201-0	CFM56	Tube assy
340-016-251-0	CFM56	Tube assy
340-016-452-0	CFM56	Tube assy
340-016-652-0	CFM56	Tube assy
340-016-852-0	CFM56	Tube assy
340-026-302-0	CFM56	Tube assy
340-026-502-0	CFM56	Tube assy
340-026-602-0	CFM56	Tube assy
340-027-505-0	CFM56-5	Manifold-CLG
340-027-506-0	CFM56-5	Manifold-CLG
340-027-507-0	CFM56-5	Manifold-CLG
340-027-555-0	CFM56-5	Manifold-Cooling
340-027-556-0	CFM56-5	Manifold-Cooling
340-027-557-0	CFM56-5	Manifold-Cooling
340-027-602-0	CFM56	Tube-Assy
340-027-603-0	CFM56	Tube-Assy
340-027-604-0	CFM56	Tube-Assy
340-029-901-0	CFM56	Tube assy
340-034-202-0	CFM56	Tube assy
340-091-604-0	CFM56	Tube assy
340-105-352-0	CFM56	Tube assy
340-130-401-0	CFM56	Tube assy

PART #	ENG #	NOMENCLATURE
340-134-052-0	CFM56	Tube assy
340-138-401-0	CFM56	Tube assy
340-138-951-0	CFM56	Tube assy
340-166-101-0	CFM56	Tube assy
355-256-005-0	CFM56-2,-3	DUCT ASSY
355-257-601-0	CFM56-2,-3	DUCT ASSY
355-257-805-0	CFM56-2,-3	FLEX LINE
366-455-602-0	CFM56	FLEX LINE
605-429-603-0	CFM56	DUCT ASSY
642-5508-503	CFM56-5	Duct Assy
642-5510-501	CFM56-5	Duct Assy
642-5511-503	CFM56-5	Duct Assy
642-5515-507	CFM56-5	Tube-Assy
642-5515-509	CFM56-5	Tube-Assy
642-5520-501	CFM56-5	Tube-Assy
642-5520-503	CFM56-5	Tube-Assy
642-5520-505	CFM56-5	Tube-Assy
642-5520-507	CFM56-5	Tube-Assy
642-5612-501	CFM56-5	Tube-Assy
642-5612-503	CFM56-5	Tube-Assy
642-5658-501	CFM56-5	Tube-Assy
642-5658-503	CFM56-5	Tube-Assy
642-5658-505	CFM56-5	Tube-Assy
642-5754-501	CFM56-5	Tube-Assy
642-5754-503	CFM56-5	Tube-Assy
642-5754-505	CFM56-5	Tube-Assy
642-5754-507	CFM56-5	Tube-Assy
642-5801-507	CFM56-5	Tube-Assy Fuel
642-5801-509	CFM56-5	Tube-Assy
642-5801-511	CFM56-5	Tube-Assy
642-5801-513	CFM56-5	Tube-Assy
642-5801-515	CFM56-5	Tube-Assy
642-5801-517	CFM56-5	Tube-Assy
642-5801-521	CFM56-5	Tube-Assy
649-430-000-0	CFM56-5	Hose-Fuel
649-430-004-0	CFM56-5	Hose-Race
649-430-005-0	CFM56-5	Hose-Oil Supply
649-430-006-0	CFM56-5	Hose-VBV Open
649-430-008-0	CFM56-5	FLEX LINE
649-430-010-0	CFM56-3	Tube-TC1 Shunt

PART #	ENG #	NOMENCLATURE
649-430-016-0	CFM56-2A	Hose-Oil
649-430-017-0	CFM56-5	Hose-Oil Rear Sump
649-430-021-0	CFM56-5	Hose-Anti Siphon
649-430-030-0	CFM56-5	Hose-Fuel
649-430-034-0	CFM56-5	Hose-Race
649-430-035-0	CFM56-5	Hose-Oil Supply
649-430-036-0	CFM56-5	Hose-VBV Open
649-430-038-0	CFM56-5	FLEX LINE
649-430-040-0	CFM56-3	Tube-TC1 Shunt
649-430-046-0	CFM56-2A	Hose-Oil
649-430-047-0	CFM56-5	Hose-Oil Rear Sump
649-430-051-0	CFM56-5	Hose-Anti Siphon
649-430-063-0	CFM56-3	Hose-Fuel Close
649-430-067-0	CFM56-5	Hose-Oil
649-430-071-0	CFM56-5	Hose-Oil
649-430-073-0	CFM56-5	Hose-VSV Rod
649-430-083-0	CFM56-3	Hose-Fuel Close
649-430-100-0	CFM56-5	FLEX LINE
649-430-113-0	CFM56-5	Hose-Oil Vent
649-430-114-0	CFM56-5	Hose-Fuel Inlet
649-430-115-0	CFM56-5	Hose-Return Heater
649-430-130-0	CFM56-5	FLEX LINE
649-430-144-0	CFM56-5	Hose-Fuel Inlet
649-430-201-0	CFM56-5	Hose-LPT Fuel
649-430-202-0	CFM56	Tube assy
649-430-203-0	CFM56-5	Hose-VBV Close
649-430-208-0	CFM56-3	Hose-Fuel Open
649-430-221-0	CFM56-5	Hose-VSV Head
649-430-231-0	CFM56-5	Hose-LPT Fuel
649-430-232-0	CFM56	Tube assy
649-430-233-0	CFM56-5	Hose-VBV Close
649-430-248-0	CFM56-3	Hose-Fuel Open
649-430-300-0	CFM56-5	Hose-Oil
649-430-330-0	CFM56-5	Hose-Oil
649-430-532-0	CFM56-5	Hose
649-432-100-0	CFM56-5	FLEX LINE
649-432-300-0	CFM56-5	Hose-Oil
649-433-030-0	CFM56-5	Hose-Fuel
649-433-034-0	CFM56-5	Hose-Race
649-433-036-0	CFM56-5	Hose-VBV Open

PART #	ENG #	NOMENCLATURE
649-433-040-0	CFM56-3	Tube-TC1 Shunt
649-433-046-0	CFM56-3	Hose-Oil Rear Sump
649-433-047-0	CFM56-5	Hose-Oil Rear Sump
649-433-049-0	CFM56-3	Hose-Oil Front Brg Supply
649-433-050-0	CFM56-3	Hose-Oil Tank Return
649-433-051-0	CFM56-5	Hose-Anti Siphon
649-433-081-0	CFM56-5	Hose-Oil Supply
649-433-083-0	CFM56-3	Hose-Fuel Close
649-433-087-0	CFM56-5	Hose-Oil
649-433-091-0	CFM56-5	Hose-Oil
649-433-093-0	CFM56-5	Hose-VSV Rod
649-433-094-0	CFM56-5	Hose
649-433-095-0	CFM56-5	Hose-PCR
649-433-100-0	CFM56-5	FLEX LINE
649-433-143-0	CFM56-5	Hose-Oil Vent
649-433-144-0	CFM56-5	Hose-Fuel Inlet
649-433-146-0	CFM56-5	Hose-Oil Heater
649-433-147-0	CFM56-5	Hose-Return Heater
649-433-150-0	CFM56-5	Hose-Return Heater
649-433-231-0	CFM56-5	Hose-LPT Fuel
649-433-233-0	CFM56-5	Hose-VBV Close
649-433-237-0	CFM56-3	Hose-Fuel Stg 5 BL V
649-433-248-0	CFM56-3	Hose-Fuel Open
649-433-250-0	CFM56-3	Hose-Fuel Actuator Return
649-433-251-0	CFM56-5	Hose-VSV Head
649-433-252-0	CFM56-5	Hose-Supply Oil
649-433-253-0	CFM56-5	Hose-Stage
649-433-330-0	CFM56-5	Hose-Oil
649-433-404-0	CFM56-5	Hose
649-433-434-0	CFM56-3	Hose-Oil Tank Overflow
649-433-532-0	CFM56-5	Hose
649-434-030-0	CFM56-5	Hose-Fuel
649-434-034-0	CFM56-5	Hose-Race
649-434-036-0	CFM56-5	Hose-VBV Open
649-434-040-0	CFM56-3	Tube-TC1 Shunt
649-434-046-0	CFM56-3	Hose-Oil Rear Sump
649-434-047-0	CFM56-5	Hose-Oil Rear Sump
649-434-049-0	CFM56-3	Hose-Oil Front Brg Supply
649-434-050-0	CFM56-3	Hose-Oil Tank Return
649-434-051-0	CFM56-5	Hose-Anti Siphon

PART #	ENG #	NOMENCLATURE
649-434-083-0	CFM56-3	Hose-Fuel Close
649-434-086-0	CFM56-5	Hose-Oil Supply
649-434-087-0	CFM56-5	Hose-Oil
649-434-091-0	CFM56-5	Hose-Oil
649-434-093-0	CFM56-5	Hose-VSV Rod
649-434-094-0	CFM56-5	Hose
649-434-095-0	CFM56-5	Hose-PCR
649-434-143-0	CFM56-5	Hose-Oil Vent
649-434-144-0	CFM56-5	Hose-Fuel Inlet
649-434-146-0	CFM56-5	Hose-Oil Heater
649-434-147-0	CFM56-5	Hose-Return Heater
649-434-149-0	CFM56-5	Hose-Return Heater
649-434-233-0	CFM56-5	Hose-VBV Close
649-434-234-0	CFM56	Tube assy
649-434-237-0	CFM56-3	Hose-Fuel Stg 5 BL V
649-434-242-0	CFM56	Tube assy
649-434-248-0	CFM56-3	Hose-Fuel Open
649-434-250-0	CFM56-3	Hose-Fuel Actuator Return
649-434-251-0	CFM56-5	Hose-VSV Head
649-434-252-0	CFM56-5	Hose-Supply Oil
649-434-253-0	CFM56-5	Hose-Stage
649-434-330-0	CFM56-5	Hose-Oil
649-434-404-0	CFM56-5	Hose
649-434-434-0	CFM56-3	Hose-Oil Tank Overflow
649-434-532-0	CFM56-5	Hose
649-436-144-0	CFM56-5	Hose-Fuel Inlet
649-436-330-0	CFM56-5	Hose-Oil
649-438-013-0	CFM56	Tube assy
649-438-201-0	CFM56	Tube assy
649-438-302-0	CFM56	Tube assy
649-671-392-0	CFM56-2A	Tube-Oil Rear Sump Supply
8135-21520	CFM56	Tube assy
9236M60G07	CFM56-2B	Manifold-Air
9236M60G08	CFM56-2B	Manifold-Air
9236M60H06	CFM56-2B	Manifold-Air
9269M98G01	CFM56	Tube assy
9297M86G05	CFM56	Tube assy
9335M34G05	CFM56-3	Manifold-Air
9335M34G06	CFM56-3	Manifold-Air
9335M34G07	CFM56-2A	Manifold-Air

PART #	ENG #	NOMENCLATURE
9342M30G01	CFM56-3	Tube-Air Signal PS3
9342M30G02	CFM56-3	Tube-Air Signal PS3
9371M65G01	CFM56	Tube assy
9371M74G01	CFM56	Tube assy
9375M10G01	CFM56-3	FUEL MANIFOLD
9375M10G03	CFM56-3	FUEL MANIFOLD
9375M12G01	CFM56-3	FUEL MANIFOLD
9375M12G03	CFM56-3	FUEL MANIFOLD
9375M14G01	CFM56-3	Tube-Drain
9375M14G02	CFM56-3	Tube-Drain
9375M16G01	CFM56-3	Manifold-Main Fuel Supply
9375M16G02	CFM56-3	Manifold-Main Fuel Supply
9375M16G03	CFM56-3	Manifold-Main Fuel Supply
9375M18G01	CFM56-3	Tube-Drain Main Fuel Supply
9375M18G02	CFM56-3	Tube-Drain Main Fuel Supply
9375M20G01	CFM56-3	Manifold-Fuel Tube
9375M20G02	CFM56-3	Manifold-Fuel Tube
9375M20G03	CFM56-3	Manifold-Fuel Tube
9375M24G01	CFM56-3	Tube CIT Sensor Bypass Pressure
9375M24G02	CFM56-3	Tube CIT Sensor Bypass Pressure
9375M24G03	CFM56-3	Tube CIT Sensor Bypass Pressure
9375M24G04	CFM56-3	Tube CIT Sensor Bypass Pressure
9375M26G01	CFM56-3	Tube-CIT Sensor Regulator Pressure
9375M26G02	CFM56-3	Tube-CIT Sensor Regulator Pressure
9375M26G03	CFM56-3	Tube-CIT Sensor Regulator Pressure
9375M26G04	CFM56-3	Tube-CIT Sensor Regulator Pressure
9375M61G01	CFM56-3	Tube-Air Bleed
9375M68G02	CFM56-3	Tube-Air 9th Stage
9375M90G03	CFM56-2A	Manifold-Fuel
9375M90G03	CFM56-3	Manifold-Fuel LH
9375M90G04	CFM56-2A	Manifold-Fuel
9375M90G04	CFM56-3	Manifold-Fuel RH
9375M90G05	CFM56-2A	Manifold-Fuel
9375M90G05	CFM56-3	Manifold-Fuel LH
9375M90G06	CFM56-2A	Manifold-Fuel
9375M90G06	CFM56-3	Manifold-Fuel RH
9375M90G07	CFM56	Manifold-Fuel
9375M90G09	CFM56-3	Manifold-Fuel LH
9375M90G10	CFM56-3	Manifold-Fuel RH
9375M90G11	CFM56-3	Manifold-Fuel LH

PART #	ENG #	NOMENCLATURE
9375M90G12	CFM56-3	Manifold-Fuel RH
9375M90G13	CFM56-3	Manifold-Fuel LH
9375M90G14	CFM56-3	Manifold-Fuel RH
9385M42G01	CFM56-3	Manifold-Fuel Drain
9385M56G01	CFM56-3	Tube-Drain
9385M85G01	CFM56-2A	Tube-Air LPT Cooling
9386M13G07	CFM56-3	Manifold-Drain RH
9386M13G08	CFM56-3	Manifold-Drain RH
9386M15G02	CFM56-3	Manifold-Fuel
9386M15G07	CFM56-3	Manifold-Drain LH
9386M17G04	CFM56-3	Manifold-Fuel Drain
9386M30G01	CFM56-3	Tube-Fuel Drain
9386M36G01	CFM56-3	Tube-Drain
9386M52G01	CFM56-3	Tube-Drain Var Stator
9386M54G01	CFM56-3	Manifold-Fuel Drain
9386M56G01	CFM56	Tube assy
9386M60G01	CFM56-3	Tube-Drain
9386M75G01	CFM56-3	Tube-Air LPT Cooling
9386M77G01	CFM56-3	Tube-Air LPT Cooling
9386M79G01	CFM56-3	Tube-Air LPT Cooling
9386M81G01	CFM56-3	Tube-Air LPT Cooling
9386M83G01	CFM56-3	Tube-Air LPT Cooling
9386M83G02	CFM56-3	Tube-Air LPT Cooling
9386M83G03	CFM56-3	Tube-Air LPT Cooling
9386M85G01	CFM56-3	Tube-Air LPT Cooling
9386M85G02	CFM56-3	Tube-Air LPT Cooling
9386M85G03	CFM56-3	FUEL MANIFOLD
9386M86G03	CFM56-3	FUEL MANIFOLD
9387M34G01	CFM56-3	Tube-Drain Fuel
9387M46G01	CFM56-3	Tube-Drain Fuel
9387M46G02	CFM56-3	Tube-Drain Fuel
9387M48G01	CFM56-3	Tube-Drain Fuel
9387M50G01	CFM56-3	Manifold-Drain
9387M50G02	CFM56-3	Manifold-Drain
9387M58G01	CFM56-3	Manifold-Drain
9387M58G02	CFM56-3	Manifold-Drain
9387M60G01	CFM56-3	Tube-Drain
9387M60G02	CFM56-3	Tube-Drain
9393M10G01	CFM56-2A	Tube-Air LPT Cooling
9393M10G02	CFM56-2A	Tube-Air LPT Cooling

PART #	ENG #	NOMENCLATURE
9393M10G03	CFM56-2A	Tube-Air LPT Cooling
9393M12G01	CFM56	Tube assy
9393M14G01	CFM56-2A	Tube-Air LPT Cooling
9393M42G03	CFM56	Tube assy
9393M44G01	CFM56-2B	Tube-Drain
9393M46G01	CFM56-2B	Manifold-Drain
9393M46G07	CFM56	Tube assy
9393M46G08	CFM56-5	Tube-Assy
9393M48G01	CFM56-5	Tube-Assy
9393M55G01	CFM56-2A	Tube-Drain Fuel
9393M59G05	CFM56-2A	Manifold-Fuel Ring
9393M60G05	CFM56-2A	Manifold-Fuel Drain LN
9393M65G01	CFM56-2A	Tube-Drain Fuel
9393M78G01	CFM56-2B	Tube-Drain
9393M90G01	CFM56-2B	Manifold-Drain
9393M93G01	CFM56-3	Tube-Drain Fuel
9394M34G01	CFM56-2A	Tube-Drain Fuel
9514M54G02	CFM56-2A	Duct-Air
9514M54G05	CFM56	Tube assy
9909874-107	CFM56-5	Duct Assy
9909875-103	CFM56-5	Duct Assy
9973M22P02	CFM56-2B	Tube-Air
9975M76G05	CFM56-3	FUEL SHROUDED MANIFOLD
AE706058-53	CFM56-5	Hose-Assy
AE706058-65	CFM56-5	Hose-Assy
AE706058-8	CFM56-5	Hose-Assy
AE707418-1	CFM56-5	Hose-Assy
AE707419-3	CFM56-5	Hose-Assy
AE707422-1	CFM56-5	Hose-Assy
AE707422-2	CFM56-5	Hose-Assy
AE709459-3	CFM56-5	Hose-Assy
AE709461-1	CFM56-5	Hose-Assy
S332A004-2	CFM56	Tube assy
S332A005-14	CFM56	Tube assy
S332A210-11	CFM56	Tube assy
S332A210-19	CFM56	Tube assy
S332A210-21	CFM56	Tube assy
S332A280-5	CFM56	Tube assy