

PART #	ENG #	NOMENCLATURE
5000202-01	JT9D	TUBE ASSY
5002378-01	JT9D	# 3 BRG NOZZLE
5004529-01	JT9D	TUBE ASSY
5004556-01	JT9D	TUBE ASSY
5002893-01	JT9D	ADAPTER-FLANGED
5003094-01	JT9D	ELBOW
5003098-01	JT9D	TUBE ASSY
5005429-01	JT9D	CONDUIT
5005719-01	JT9D	TUBE COOLING AIR TURBINE LOWER RIGHT FRNT
5005726-01	JT9D	TUBE COOLING AIR TURBINE LOWER RIGHT REAR
5005734-01	JT9D	TUBE COOLING AIR TURBINE UPPER RIGHT REAR
5005920-01	JT9D	TUBE COOLING, TURBINE, ASSY OF
5005938-01	JT9D	#1 & #2 BRG BREATHER TUBE
5006216-01	JT9D	MFLD PS3 CMPRSSR STSTR CNTRL RGT ASSY OF
5006514-01	JT9D	PT7 AVERAGE PRESSURE PROBE
5006615-01	JT9D	PT7 TUBE
5006629-01	JT9D	TUBE ASSY
5006632-01	JT9D	#4 BRG AIR SUPPLY TUBE
5006634-01	JT9D	TUBE ASSY
5006634-03	JT9D	TUBE ASSY
5006635-01	JT9D	TUBE ASSY
5006638-04	JT9D	PS4 TURB CLG AIR MOD VALVE MANIFOLD
5006646-01	JT9D	TUBE ASSY
5006651-01	JT9D	PS4 FUEL CONTROL TUBE
5006785-01	JT9D	MANIFOLD TURBINE CASE; COOLING AIR
5006786-01	JT9D	TUBE, ASSY, JT9D-7Q
5006798-01	JT9D	TUBE ASSY
5006808-01	JT9D	TUBE ASSY
5006809-01	JT9D	TUBE ASSY
5006811-01	JT9D	VALVE SENSING TUBE
5006814-01	JT9D	TUBE ASSY
5006823-01	JT9D	TUBE ASSY
5006846-03	JT9D	MANIFOLD ASSY
5006856-01	JT9D	TUBE ASSY
5006862-01	JT9D	SEC. FUEL NOZZLE SPY
5006864-01	JT9D	SEC. FUEL NOZZLE SPY
5006889-01	JT9D	TCC VALVE PS4 TUBE
5006896-01	JT9D	BLEED VALVE SPY MANIFOLD
5006948-01	JT9D	TUBE ASSY
5006952-01	JT9D	TUBE ASSY

PART #	ENG #	NOMENCLATURE
5006992-01	JT9D	SENSOR & CONTROL TUBE
5006993-01	JT9D	TUBE ASSY
5006994-01	JT9D	TUBE ASSY
5007001-01	JT9D	TUBE ASSY
5007002-01	JT9D	TUBE ASSY
5007004-01	JT9D	TUBE ASSY
5007007-01	JT9D	TUBE ASSY
5007023-01	JT9D	TUBE ASSY
5007025-01	JT9D	TUBE ASSY
5007026-01	JT9D	TUBE ASSY
5007028-01	JT9D	TUBE ASSY
5007029-01	JT9D	EEC, PT7 TUBE
5007030-01	JT9D	#4 BRG PRESSURE TUBE
5007037-01	JT9D	TUBE ASSY
5007046-01	JT9D	TUBE FUEL SIG, BL CYL VAL, ASSY OF
5007072-01	JT9D	PS4 TURBINE CLL TUBE
5007087-01	JT9D	TUBE,PSA, TCC MOB VAL, ASSY OF
5007088-01	JT9D	PS4 TCC MOD VAL
5007089-01	JT9D	TUBE ASSY
5007093-01	JT9D	TUBE, FUEL HEATER OIL RETURN
5007114-01	JT9D	PT7 MANIFOLD
5007126-01	JT9D	TUBE ASSY
5007131-01	JT9D	TUBE ASSY
5007140-01	JT9D	TUBE DRAIN #3 BEARING ASSY OF
5007142-01	JT9D	TUBE ASSY
5007143-01	JT9D	BLEED VALVE SUPPLY TUBE
5007145-01	JT9D	TUBE PS4, SURGE DETECTOR, ASSY OF
5007160-01	JT9D	TUBE ASSY
5007164-01	JT9D	TCC MOD VALAE PS4 TUBE
5007165-01	JT9D	TUBE, PS4 TURB CASE CLG MOD VLV
5007166-01	JT9D	TUBE ASSY
5007167-01	JT9D	MANIFOLD-SPY BL VAL,ASSY OF
5007168-01	JT9D	MFLD PS4 TCC MOD VAL ASSY OF
5007171-01	JT9D	TUBE ASSY
5007172-01	JT9D	TUBE ASSY
5007173-01	JT9D	PS4 BLEED VALVE MANIFOLD
5007174-01	JT9D	TUBE ASSY
5007184-01	JT9D	MAINIFOLD-PRESS SENSING BL DIFFERENTIAL SW
5007192-01	JT9D	#4 BEARING SEAL AIR TUBE
5007193-01	JT9D	TUBE-PRES, #4 BRG, ASSY OF

PART #	ENG #	NOMENCLATURE
5007197-01	JT9D	TUBE ASSY
5007199-01	JT9D	#3 BRG. BREATHER TUBE
5007202-01	JT9D	TUBE ASSY
5007210-01	JT9D	AIR SUPPLY #4 BEARING SEAL, ASSY OF
5007214-01	JT9D	DEAERATOR TUBE
5007282-01	JT9D	TUBE ASSY
5007504-01	JT9D	PRIMARY FUEL NOZZLE SUPPLY
5007513-01	JT9D	TUBE, SPY FUEL NOZZLE, PRI, ASSY OF
5007534-01	JT9D	SECONDARY FUEL NOZZLE SPY TUBE
5008009-01	JT9D	TUBE ASSY
5008021-01	JT9D	CONTROL VALVE SUPPLY TUBE
5008045-01	JT9D	TUBE OIL, COOLER INLET, ASSY OF
5008047-01	JT9D	MAINFOLD, PRESS, GEARBOX, ASSY OF
5008051-01	JT9D	TUBE SENSING, MAIN OIL PRESSURE, ASSY OF
5008073-01	JT9D	DRAIN TUBE
5008077-01	JT9D	TUBE ASSY
5008080-01	JT9D	FUEL HEATER RETURN TUBE
5008082-01	JT9D	TUBE, DRAIN, #3 BEARING
5008088-01	JT9D	TUBE ASSY
5008089-01	JT9D	OIL COOLER FUEL TUBE
5008091-01	JT9D	TUBE ASSY
5008092-01	JT9D	DRAIN TUBE
5008097-01	JT9D	TUBE ASSY
5008098-01	JT9D	DRAIN TUBE
5008104-01	JT9D	FUEL MANIFOLD BLEED CONTROL
5008105-01	JT9D	TUBE ASSY
515242	JT9D	TUBE PRES SNSNG SFFSR INTRD, INTNL, ASSY OF
597498	JT9D	TUBE HEAT SHIELD ASSY
599274	JT9D	TUBE ASSY
60B00254-36	JT9D	HOSE ASSY
60B90135-1	JT9D	PUNCH & POLISH
612923	JT9D	BLEED CONVERTER VALVE FUEL DRAIN
613115	JT9D	RIGHT PT7 MAIFOLD
613116	JT9D	TUBE ASSY
613117	JT9D	TUBE, PT7, UPPER LEFT, ASSY OF
613265	JT9D	ELBOW
613731	JT9D	LOWER LEFT TUBE ASSY
618548	JT9D	TUBE PRES #2 BRG INTERMEDIATE INTNL A OF
622129	JT9D	OIL COOLER INLET TUBE CONNECTOR
627881	JT9D	#1 BRG AIR SUPPLY TUBE

PART #	ENG #	NOMENCLATURE
628281	JT9D	CONNECTOR
629554	JT9D	CONNECTOR
634935	JT9D	TUBE ASSY
634937	JT9D	TUBE ASSY
637088	JT9D	TUBE ASSY
640654	JT9D	TUBE ASSY
641497	JT9D	MNFLD, FUEL SIGAL, CMPR STATR CONTRL A OF
644168	JT9D	TUBE ASSY
644818	JT9D	TUBE ASSY
645213	JT9D	MANIFOLD-SUPPLY, BLD VLV, RIGHT, ASSY OF
645786	JT9D	MANIFOLD-HYD.RETURN,FUEL CONTROL INLET,FRT
646290	JT9D	COMP.STATOR CYL HYD RETURN ASSY
646991	JT9D	TUBE, SUPPLY FUEL NOZZLE, PRIMARY, ASSY OF
646993	JT9D	TUBE SUPPLY FUEL NOZZLE, SECONDARY, ASSY OF
647029	JT9D	TUBE SUPPLY FUEL NOZZLE PRIMARY, ASSY OF
647034	JT9D	TUBE SUPPLY FUEL NOZZLE PRIMARY, ASSY OF
647038	JT9D	FUEL NOZZLE #10 POSITION TUBE ASSY
647040	JT9D	TUBE,SUPPLY FUEL NOZZLE,SECONDARY, ASSY
647043	JT9D	TUBE SUPPLY FUEL NOZZLE PRIMARY, ASSY OF
647046	JT9D	PRIMARY FUEL NOZZLE SUPPLY
647101	JT9D	TUBE SUPPLY FUEL NOZZLE PRIMARY, ASSY OF
647105	JT9D	TUBE SUPPLY FUEL NOZZLE, SECONDARY, ASSY OF
647107	JT9D	TUBE SUPPLY FUEL NOZZLE PRIMARY, ASSY OF
647117	JT9D	TUBE SUPPLY FUEL NOZZLE, SECONDARY, ASSY OF
647122	JT9D	TUBE SUPPLY FUEL NOZZLE, SECONDARY, ASSY OF
647124	JT9D	TUBE SUPPLY FUEL NOZZLE PRIMARY, ASSY OF
647128	JT9D	TUBE SUPPLY FUEL NOZZLE PRIMARY, ASSY OF
647134	JT9D	TUBE ASSY
647136	JT9D	SECONDARY FUEL NOZZLE SUPPLY
647251	JT9D	MANIFOLD, WATER INJECTION RH
647312	JT9D	TUBE-SUPPLY,FUEL MANIFOLD,PRIMARY, A OF
647409	JT9D	TUBE SCAVENGE ANGLE GEARBOX, ASSY OF
647420	JT9D	ELBOW
649781	JT9D	FRONT #4 BEARING SCAVENGE TUBE, ASSY OF
651782	JT9D	CONNECTOR FOR TUBE
65-19573-1	JT9D	DUCT ASSY
653171	JT9D	MNFLD COOLNG AIR,#3BRG,LOWER RIGHT ASSY OF
654187	JT9D	TUBE,PS4,FUEL CONTROL,UPPER ASSY OF
655837	JT9D	TUBE ASSY
655858	JT9D	TUBE HYD PRESSRE, COMPRSR STATR CYL, OPEN

PART #	ENG #	NOMENCLATURE
656176	JT9D	TUBE, SCAVE,#4BRG,INNER INTERVAL,ASSY OF
656541	JT9D	TUBE-PRESSURE GEARBOX ASSY OF
65B90211-9	JT9D	TUBE ASSY
65B90242-4	JT9D	ENG 15TH STA PNEU
65B90257-9	JT9D	FAN THRUST REVERSER
65B91263-15	JT9D	DUCT ASSY
65B91263-18	JT9D	DUCT ASSY
65B92804-600	JT9D	DUCT ASSY
65B93011-13	JT9D	DUCT ASSY
65b9311-14	JT9D	DUCT ASSY
65B93011-17	JT9D	DUCT ASSY
661668	JT9D	MNFLD FUEL, PRIMARY RIGHT ASSY OF
664620	JT9D	TUBE ASSY
667429	JT9D	MANIFOLD, PS4 BLEED CONTROL
666998	JT9D	DUAL FUEL MNFLD
667412	JT9D	TUBE, SUPPLY BLD LINEAR DIRECTIONAL CONT
667414	JT9D	MNFLD SUPPLY, BLEED VALVE UPPER LEFT A OF
667432	JT9D	MANIFOLD, FUEL BLEED CONTROL OUTLET
669517	JT9D	TUBE PRESSURE, MAIN BEARING INTERMED A OF
669570	JT9D	MNFLD HYD, COMPRESSR,STATR CONTRL FRONT A OF
669603	JT9D	MAIN BRG BREATHER TUBE TUBE-FUEL SENSING, TT2 SENSOR OUTLET
669718	JT9D	FRONT
669720	JT9D	MANIFOLD, FUEL SENSING TT2 SENSING OUTLET
669724	JT9D	TUBE,FUEL SIGNAL, CMPRSSR,STATR CYLDR VLV A
669936	JT9D	TUBE-PT3, COMPR STATOR CTRL, RR A OF
670336	JT9D	MNFLD,BREATHER#3 BEARING A OF
670337	JT9D	MNFLD BREATHER MAIN BEARING FRONT A OF
670607	JT9D	MANFOLD BREATHER #1 & #2 BEARING, A OF
670640	JT9D	TUBE, SCAV, #4 BEARING REAR
670663	JT9D	MAINFOLD, #4 BRG, OIL PRESSURE TUBE
671165	JT9D	TUBE OIL COOLING INLET FRONT, A OF
671169	JT9D	MAIN BEARING PRESSURE MAIFOLD
671179	JT9D	TUBE SENSING OIL STRAINER, A OF
671187	JT9D	TUBE FUEL, OIL COOLER, INLET RIGHT, A OF
671189	JT9D	TUBE FUEL OIL COOLER OUTLET FRONT, A OF
671191	JT9D	TUBE OIL COOLER OUTLET REAR, A OF
671202	JT9D	TUBE, OIL COOLER OIL INTER FRT
671418	JT9D	TUBE, FUEL CONTROL, INTERMEDIATE
671941	JT9D	MAINFOLD #1 & #2 BRG BREATHER
671992	JT9D	TUBE SCAVENGE #4 BEARING FRONT, A OF

PART #	ENG #	NOMENCLATURE
671996	JT9D	TUBE SCAVENGE #3 BEARING FRONT, A OF
672120	JT9D	MANIFOLD PT3 COMPRSSR STATOR SCTRL LEFT
672122	JT9D	COMP.STATOR CONTROL PS3&PT3 TUBE
672178	JT9D	TUBE ASSY
672287	JT9D	MANIFOLD, PRESSURE #1 & 2 BRG
67228	JT9D	TUBE SENSING OIL STRAINER, A OF
672293	JT9D	MANIFOLD ASSY
67209	JT9D	TUBE SUPPLY FUEL NOZZLE SECONDARY, A OF
672313	JT9D	MAINFOLD
672315	JT9D	TUBE-SUPPLY, FUEL NOZZLE, PRIMARY, A OF
672393	JT9D	TUBE FUEL OIL COOLER INLET, A OF
672395	JT9D	TUBE OIL COOLER, INLET, A OF
672408	JT9D	MANIFOLD, COMPR STA CONTROL PS3
672416	JT9D	MANIFOLD, COMPR STA CONTROL PS3
672418	JT9D	TUBE HYD COMPRSSR STATR CYR CLOSE, A OF
672420	JT9D	TUBE, COMPR STATOR CONTROL
672426	JT9D	TUBE ASSY
672429	JT9D	MNFLD,HYD,RETURN FUEL CTRL INLET LOWER A OF
672435	JT9D	MNFLD FUEL SGNL BLD, OVRIDE SURGE DETCTR
672438	JT9D	MANIFOLD HYD ACTG CYL VLV, A OF
672585	JT9D	BEARING #3 COOLING AIR TUBE
672735	JT9D	TUBE PS4 BLEED CNTRL REAR, A OF
672738	JT9D	FRONT #4 BRG COOLING AIR TUBE
672813	JT9D	TUBE ASSY
672817	JT9D	TUBE ASSY
672909	JT9D	MNFLD PS3 CMPR STATOR CNTRL A OF
672910	JT9D	TUBE ASSY
672912	JT9D	#2 BRG SEAL AIR TUBE ASSY
673206	JT9D	CONNECTOR
673272	JT9D	TUBE, COMPR STATOR CYL
673274	JT9D	TUBE, HYD CMPRSSR STATR, CYL CLOSE, A OF
673395	JT9D	MNFLD FUEL PRIMARY LEFT, A OF
673439	JT9D	MANFLD ASSY OF, AIR VENT RIGHT
673495	JT9D	#3 BRG BREATHER TUBE, ASSY OF
674413	JT9D	TUBE ASSY
674454	JT9D	TUBE SPY FUEL NOZ SEC LEFT, A OF
675808	JT9D	ADAPTER, TUBE TO BOSS
676814	JT9D	#10 POS. FUEL NOZZLE TUBE ASSY
677298	JT9D	TUBE SUPPLY FUEL NOZZLE PRIMARY LEFT, A OF
677350	JT9D	TUBE SUPPLY FUEL NOZ SEC LEFT, A OF

PART #	ENG #	NOMENCLATURE
677353	JT9D	TUBE SUPPLY FUEL, PRIMARY LEFT, ASSY OF
677355	JT9D	TUBE BREATHER MAIN BEARING REAR, A OF
677370	JT9D	MAINFOLD
677399	JT9D	MNFLD FUEL SGNL BLD VLV STRL, A OF
678189	JT9D	TUBE PRESSURE, CMPR STATOR CTRL REAR A OF
678194	JT9D	TUBE, COMPR STATOR CNTRL FUEL RETURN
678195	JT9D	TUBE PRESSURE, COMP STR, CNTRL FRNT A OF
678937	JT9D	TUBE-AIR, FUEL HEATER, INTRMDTE, ASSY OF
678960	JT9D	TUBE PS4 BLD CTRL RSTRCTR INLET, REAR, A OF
679991	JT9D	TUBE PS4 BLD OVERRIDE SURGE DCTR REAR, A OF
690046	JT9D	TUBE, BLD CONTROL PS4 RESTRICTOR
690058	JT9D	TUBE, BLD CONTROL PS4 RESTRICTOR
690343	JT9D	BLD CONTRL RESTRICTOR AIR VENT TUBE
690357	JT9D	SECONDARY FUEL SUPPLY MNFLD
690358	JT9D	MNFLD FUEL SECONDARY LEFT, A OF
690359	JT9D	TUBE ASSY
690361	JT9D	MNFLD SUPPLY FUEL SECONDARY, A OF
692372	JT9D	UPPER BLD VLV CTRL PS4 MNFLD
692659	JT9D	TUBE, PS5, AIRFRAME, A OF
69-29151-1	JT9D	DUST ASSY
69-29152-1	JT9D	DUST ASSY
693057	JT9D	L.F. SHIELDED MNFLD
693573	JT9D	TUBE ASSY
693576	JT9D	TUBE-PS5,AIRFRAME, A OF
693946	JT9D	MNFLD-PS4,BLD VLV CTRL, UPPER, A OF
694237	JT9D	TUBE ASSY
694703	JT9D	#3 BEARING SVAVENGE EJECTOR
695205	JT9D	TUBE ASSY
696888	JT9D	TUBE, COOLING AIR #3 BEARING, A OF
697896	JT9D	TUBE, PRESSURE,GEARBOX. A OF
697913	JT9D	TUBE, SPY FUEL NOZ, PRIMARY RIGHT, A OF
699123	JT9D	TUBE ASSY
699602	JT9D	#1 & #2 BEARING BREATHER MNFLD
669603	JT9D	MAIN BRG BREATHER TUBE
698979	JT9D	TUBE ASSY
699603	JT9D	MAIN BRG BREATHER TUBE
699718	JT9D	TUBE ASSY
699897	JT9D	MNFLD, COOLING AIR POWER, CABLE, A OF
699923	JT9D	TUBE, SCAVENGE #4 BEARING REAR, A OF
70R050	JT9D	PRESSURE TUBE

PART #	ENG #	NOMENCLATURE
702458	JT9D	TUBE,PS4,BLD CNTRL VLV, A OF
704047	JT9D	TUBE-AIR, FUEL HEATHER FRONT, A OF
704287	JT9D	TRANSFER TUBE
704754	JT9D	MFLD FUEL SGNAL
704757	JT9D	TUBE ASSY
704835	JT9D	TUBE , SCAVENGE #4 BRG, FRONT, A OF
705591	JT9D	CONNECTOR
706386	JT9D	SLEEVE
706918	JT9D	TUBE ASSY
708528	JT9D	MANIFOLD-PRESS, #4 BRG, FRNT, ASSY OF
708529	JT9D	TUBE ASSY
708708	JT9D	TUBE-AIR VENT, #3 BRG, RIGHT FRONT, A OF
708709	JT9D	MNFLD, AIR VENT, #3 BRG, RT.RR.A OF
708714	JT9D	TUBE ASSY
709335	JT9D	MNFLD, PRES, MAIN BRG, FNT, ASSY OF
709561	JT9D	TUBE ASSY
709563	JT9D	TUBE ASSY
709564	JT9D	TUBE ASSY
709640	JT9D	TUBE FUEL SIGNAL BLD VLV CTRL LOWER
709657	JT9D	TUBE, SCAVG #3 BEARING LOWER, A OF
709659	JT9D	TUBE SUPPLY FUEL NOZ PRIMARY LWR A OF
709661	JT9D	TUBE,SUPPLY,FUEL NOZ SEC LOWER ASSY OF
71R050	JT9D	NOZZLE
710787	JT9D	TUBE, AIR SUPPLY, #1 BEARING SEAL
710799	JT9D	MNFLD, FUEL SIG, BLD CYL,VLV,REAR,ASSY OF
710891	JT9D	MNFLD, FUEL SIGNAL, BLD CYL, VLV, ASSY OF
711016	JT9D	TUBE, BLD OVERRIDE PS4
711036	JT9D	TUBE ASSY
711038	JT9D	TUBE ASSY
711040	JT9D	PS3 MANIFOLD
711047	JT9D	MANIFOLD, PT3 COMPR STAATOR CONTROL
711066	JT9D	TUBE,ANTI-ICING INTRMDTE UPPER REAR, A OF
711085	JT9D	MANIFOLD-ANTI-ICING, INTRMDTE LOWER RR, A OF
711160	JT9D	TUBE ASSY
711256	JT9D	TUBE ASSY
711290	JT9D	UPPER LEFT BLEED CONTROL FUEL SGNL ASSY
711358	JT9D	MNFLD, FUEL DRAIN SURGE STCTR, CONCRTER VLV
711388	JT9D	MNFLD FUEL BLD VLV CONTROL OUTLET
711411	JT9D	MNFLD, SUPPLY, BLD DRCTNL CNTRL VLV A OF
711454	JT9D	MANIFOLD, #3 BRG VENT RT FRT

PART #	ENG #	NOMENCLATURE
711456	JT9D	TUBE, #3 BRG RT REAR
711461	JT9D	TUBE-ANT VENT, #3 BRG, LEFT FRONT, A OF
711545	JT9D	MANIFOLD SUPPLY BLEED VLV UPPER LEFT
711713	JT9D	#4 BRG COOLING AIR TUBE
711719	JT9D	TUBE ASSY
711797	JT9D	TUBE AIR, FUEL HEATER, INTRMDTE LOWER A OF
711799	JT9D	TUBE-AIR, FUEL HEATER, INTRMED UPPER, A OF
711872	JT9D	TUBE ASSY
711958	JT9D	MNFLD, SUPPLY, BLD VLV, LOWER LEFT FRONT
711961	JT9D	MANIFOLD, 15TH STAGE BLEED SYS
711982	JT9D	MANIFOLD, PS4 BLEED VLV CNTRL, FRONT A OF
711989	JT9D	PS4 BLEED VALVE CONTROL TUBE
712478	JT9D	TUBE, PRESSURE HYD
712482	JT9D	TUBE, PS3, CMPRSSR STATOR CNTRL FRONT A OF
712692	JT9D	TUBE-BREATHER, MAIN BRG INTRMDTE, A OF
712717	JT9D	TUBE SUPPLY, FUEL, NOZ, SEC, LOWER RIGHT A OF
712719	JT9D	MNFLD, FUEL, SEC RIGHT, A OF
713597	JT9D	TUBE, #3 BEARING PRESS MANIFLOD
713605	JT9D	TUBE,PS5,AIRFRAME,FRONT INTRNL A OF
713984	JT9D	TUBE ASSY
714460	JT9D	MNFLD,PRESSURE #3 & 4 BEARING, UPPER A OF
714461	JT9D	TUBE-PRESSURE, #3 & 4 BEARING, LOWER A OF
715132	JT9D	MNFLD-PRESSURE, #3 &4, BEARING, REAR, A OF
715887	JT9D	TUBE, SCAV, #3 BRG, REAR, CONSISTS OF T
715889	JT9D	TUBE, SCAVENGE #3 BREG INTRMDTE, A OF
716402	JT9D	TUBE, BLD CNTRL PS4 RESTRICTOR
716409	JT9D	TUBE, BLD ACT CYL FUEL SIGNAL
716411	JT9D	TUBE, BLD ACT FUEL SIGNAL
716414	JT9D	MNFLD, PS4 BLD CNTRL RESTRCTR OUTLET, A OF
716640	JT9D	TUBE SENSING PRES RELIEF VLV LOWER, A OF
716809	JT9D	TUBE,PS4 BLD VLV CNTRL REAR
716877	JT9D	TUBE, PRESSURE, GEARBOX, ASSY OF
716879	JT9D	TUBE, RETURN COMPR STATOR CONTROL
716881	JT9D	MNFLD, RETURN COMPR STATR CNTRL FNT, A OF
716884	JT9D	TUBE,FUEL SIG COMPR STATR CNTRL REAR, A OF
716886	JT9D	TUBE, COMPR STATOR CYL FUEL SIGNAL
716888	JT9D	TUBE, HYD, COMPR STATR CNTRL REAR, ASSY OF
716890	JT9D	MNFLD, HYD, COMPR STATR CNTL FNT, A OF
716909	JT9D	MNFLD, SUPPLY, BLEED CNVTR, VALVE, A OF
717491	JT9D	TUBE, HYD CMPRSSR, STATR CYL CLOSE, A OF

PART #	ENG #	NOMENCLATURE
717637	JT9D	MNFLD, PS4 BLD CNTRL INTRMDTE, A OF
718547	JT9D	TUBE-FUEL, OIL COOLER INLET, INTRMDTE, A OF
718549	JT9D	TUBE, FUEL, OIL COOLER INLET, LEFT A OF
718988	JT9D	TUBE, ANTI-ICING INTRMDTE, UPPER, REAR A OF
719322	JT9D	TUBE, FUEL CONTROL PS4 REAR
719396	JT9D	#3 BEARING BREATHER MANIFOLD
719411	JT9D	TUBE, COOLING AIR #3 &4, BREG FRONT, A OF
719413	JT9D	MANIFOLD, #4 BRG, REAR COOLING AIR
719836	JT9D	#3 & #4 BREG.AIR COOLING MNFLD
719885	JT9D	TUBE OIL COOLER INLET UPPER
719891	JT9D	TUBE SNSING PRSSRE RELIEF VLV INTRMDTE A OF
719949	JT9D	TUBE ASSY
725116	JT9D	TUBE, AIR SUPPLY #1 BEARING SEAL A OF
725194	JT9D	TUBE, AIR, SHUT OFF VLV A OF
725434	JT9D	MANIFOLD
725439	JT9D	TUBE ASSY
725542	JT9D	INTERNAL PRESSURE MANIFOLD
725543	JT9D	INTERNAL PRESSURE MANIFOLD ASSY
726876	JT9D	TUBE-COOLING AIR #3 BEARING, UPPER RGT, A OF
726916	JT9D	TUBE-FUEL, BLD VLV CNTRL OUTLET, FNT A OF
726918	JT9D	TUBE FUEL SIGNAL, BLD VLV CNTRL UPPER A OF
726927	JT9D	MNFLD, HYDRAULIC BLD CYL VLV A OF
727549	JT9D	TUBE, BLEED CONTROL INLET
727553	JT9D	TUBE PS4, BLD CNTRL RESTRL RSTRCTR OUTLET FRNT A OF
727554	JT9D	TUBE COOLING AIR #4 BEARING INTRMDTE
727555	JT9D	TUBE PRESSURE #4 BEARING REAR A OF
727558	JT9D	TUBE PRESSURE #4 BEARING FRONT A OF
727559	JT9D	TUBE AIR VENT BLD CNTRL PS4, RSTRCTR A OF
727561	JT9D	UPPER REAR PS4 BLD VLV CNTRL
727564	JT9D	TUBE ASSY
727656	JT9D	TUBE PS4, BLD CNTRL RSTRCTR INLET FRNT A OF
727567	JT9D	TUBE COOLING AIR #4 BEARING INTRMDTE
727568	JT9D	TUBE ASSY
727570	JT9D	TUBE PS4 CNTRL RSTRCTR OUTLET RNT, A OF
727573	JT9D	PS4 BLEED CONTROL RESTRICTOR OUTLET
727714	JT9D	MNFLD, PRESSURE, #3 BRG, INNER INT, A OF
728380	JT9D	MNFLD, FUEL SIG, BLD CYL VLV OVERRIDE,A OF
728432	JT9D	TUBE, PS4 BLD CNTRL, A OF
728511	JT9D	TUBE, PS4 CNTRL RESTCTR INLET FNT, A OF
728512	JT9D	TUBE, PS4 SURE DET REAR

PART #	ENG #	NOMENCLATURE
728719	JT9D	TUBE-PS4 BLEED CONTROL
728722	JT9D	TUBE,SUPPLY,FUEL NOZ, SEC RIGHT, ASSY OF
728978	JT9D	TUBE SGNAL CMPRSSR STATR SYL VLV, A OF
729268	JT9D	TUBE ASSY
729271	JT9D	HYDRAULIC MANFOLD
729277	JT9D	MANIFOLD, FUEL SGNAL BLD CYL VLV OVERR
729372	JT9D	TUBE, AIR, VENT VALVE OUTLET, ASSY OF
729373	JT9D	TUBE, BLD CNTRL PS4 RESTRICTOR
729381	JT9D	MANIFOLD HYD RETURN FUEL CTRL INLET UPP
729383	JT9D	MANFOLD-FUEL, BLD VLV STRL OUTLET RR A OF
730306	JT9D	TUBE, AIR BREATHER MAIN BRG #1 & 2
730519	JT9D	TUBE, FUEL BLD VLV OUTLET UPPER REAR,A OF
730913	JT9D	BLEED VALVE SUPPLY MNAIFOLD
731073	JT9D	TUBE, PS4, BLD CNTRL RSTRCTR OUTLET FNT, A OF
731284	JT9D	TUBE, SENSING PRESSURE RELIF VLV RIGHT
731287	JT9D	MANIFOLD ASSY- #1 AND #2 BEARING
731637	JT9D	TUBE, ANTI-ICE GEARBOX DRIVE SGAFT OTER
731957	JT9D	MANIFOLD-PS4, BLDVLV CTRL, FRONT, ASSY OF
731982	JT9D	TUBE, OIL TANK UPPER
732509	JT9D	MNFOLD, ANTI-SIPHON, OIL TANK, LOWER, ASSY OF
732933	JT9D	TUBE,ASSY,PS5 AIRFRAME
733291	JT9D	LOWER OIL COOLER INLER INET TUBE
733698	JT9D	PS3 PT7 PRESSURE PROBE
734616	JT9D	MANIFOLD, MAIN BRG REAR OIL PRESSURE
735863	JT9D	MANIFOLD
736225	JT9D	TUBE, SENSING PRESSRE RELIEF VLV LEFT, A OF
736409	JT9D	TUBE-PS4, BLD CNTRL, INTERMEDIATE, ASSY OF
737269	JT9D	TUBE ASSY
737500	JT9D	TUBE, FUEL HEATER ENGINE JT9D-7F
738528	JT9D	TUBE ASSY
738535	JT9D	TUBE ASSY
738537	JT9D	TUBE ASSY
738538	JT9D	TUBE ASSY
739236	JT9D	MANIFOLD, FUEL CONTROL FRT PS4
739658	JT9D	TUBE, FUEL HEATER REAR AIR
740927	JT9D	TUBE, #3 BRG LT FRT
740929	JT9D	TUBE , AIR VENT #3 BRG, LEFT REAR, ASSY OF
743415	JT9D	TUBE, PRESSRE #3 BEARING OUTLET INTERNAL A OF
74317	JT9D	TUBE SCAVENGE #3 BEARING INTERNAL ASSY OF
744456	JT9D	TUBE ASSY

PART #	ENG #	NOMENCLATURE
746527	JT9D	MNFLD-HYDRAULIC PRSSRE, BLD SWITCH ASSY OF
747149	JT9D	MAINIFOLD-HYD PRES, BLD SWITCH, ASSY OF
748769	JT9D	TUBE-SENSING, PRESSURE RELEF VLV, A OF
749117	JT9D	MNFLD SUPPLY,BLD VLV LEFT ASSY OF
749791	JT9D	TUBE,PS5,AIRFRAME INTERMEDIATE, A OF
749792	JT9D	TUBE PS5 AIRFRAME REAR #3 BRG
749796	JT9D	TUBE ASSY
756124	JT9D	TUBE ASSY
756726	JT9D	TUBE,PS4 BLD CONTRL RSTRCTR OUTLET REAR A OF
759950	JT9D	SECONARY FUEL NOZZLE SUPPLY
759980	JT9D	TUBE-SUPPLY, BLEED VALVE, LOWER
760397	JT9D	TUBE ASSY
760403	JT9D	TUBE-DRAIN, #3 BRG OUTLER INTERNAL, A OF
760496	JT9D	TUBE-PS5, AIRFRAME, OUTLER INTERNAL, A OF
761265	JT9D	MANIFOLD SUPPLY BLEED VALVE FRONT A OF
761267	JT9D	TUBE-SUPPLY, BLD VLV UPPER ASSY OF
761269	JT9D	TUBE ASSY
761271	JT9D	TUBE-SUPPLY, BLD VLV, UPPER LEFT, A OF
761277	JT9D	TUBE, SUPPLY BLEED VALVE
761538	JT9D	TUBE ASSY
761543	JT9D	TUBE ASSY
766438	JT9D	INTERNAL SCAVENGE #3 BEARIN
766625	JT9D	TUBE, LARGE OIL TANK ENG JT9D-7FCN
766683	JT9D	UPPER REAR SUPPLY BLD VLV TUBE
768624	JT9D	TUBE, BLEED VALVE CONTROL, REAR
768739	JT9D	TUBE, DRAIN #3 BEARING FRONT, ASSY OF
769230	JT9D	#4 BREG NOZZLE ASSY
769472	JT9D	MANIFOLD, HYD RET, FUEL PUMP INLET REAR, A OF
770039	JT9D	UPPER LEFT BLV VLV SUPPLY TUBE
771323	JT9D	MANIFOLD ASSY
771925	JT9D	TUBE, #3BREG AIR VENT
771975	JT9D	TUBE-SCAVENGE, ANGLE GEARBOX, ASSY OF
772376	JT9D	ADAPTER
772432	JT9D	TUBE ASSY
772823	JT9D	SERMENT,BAND,1ST STG TURBINE;7Q
772986	JT9D	ELBOW-FUEL HEATER
773306	JT9D	TUBE, OIL VENT #3 BRG OUTLET INTENAL, A OF
773433	JT9D	ELBOW ASSY
773639	JT9D	TUBE FUEL, OIL COOLER OUTLET, ASSY OF
773804	JT9D	ELBOW ASSY

PART #	ENG #	NOMENCLATURE
773842	JT9D	TUBE, FUEL SIGNAL, BLEED CYL VALVE, UPPER
773844	JT9D	TUBE ASSY
773846	JT9D	TUBE ASSY
773848	JT9D	TUBE ASSY
773850	JT9D	TUBE ASSY
773863	JT9D	COOLING AIR TUBE
773923	JT9D	TUBE, SUPPLY, FUEL NOZZLE, ASSY OF
773925	JT9D	TUBE, SUPPLY FUEL NOZZLE SECONDARY, A OF
773929	JT9D	TUBE, SUPPLY FUEL NOZZLE SEC, ASSY OF
773999	JT9D	TUBE ASSY
774353	JT9D	TUBE ASSY
774378	JT9D	TUBE SENSING PRESSURE RELIF VLV, LEFT A OF
774451	JT9D	TUBE, CONNECTOR
774513	JT9D	TUBE, OIL INLET LOWER ASSY OF
774515	JT9D	ELBOW
774517	JT9D	TUBE OIL COOLER INLET UPPER, ASSY OF
774540	JT9D	TUBE AIR, FUEL HEATER OUTLET, ASSY OF
774548	JT9D	TUBE ASSY
774630	JT9D	TUBE FUEL, BLD VLV CNTRL OUTLET UPPER, A OF
774639	JT9D	TUBE SUPPLY BLD VLV CYL CLOSE REAR, A OF
775173	JT9D	AIR TUBE ASSEMBLY
775189	JT9D	MANIFOLD
775190	JT9D	MANIFOLD, PS3
775191	JT9D	MANIFOLD, PS3
775194	JT9D	TUBE ASSY
775216	JT9D	TUBE-AIR SHUT OFF VALVE
775581	JT9D	MANIFOLD, BLEED VALVE, SUPPLY
775589	JT9D	MANIFOLD, PS4
775613	JT9D	MANIFOLD
775646	JT9D	TUBE SUPPLY BLD VLV CYL OPEN, REAR, A OF
775647	JT9D	BLEED VALVE CYLINDER SUPPLY
775660	JT9D	TUBE, FUEL SIGNAL, BLD, VLV, CYL OVERRIDE, A OF
775663	JT9D	TUBE HYD RETURN FUEL CNTRL INLET REAR, A OF
775666	JT9D	TUBE-HYD PRES, CMPR STATR CNTRL, A OF
775669	JT9D	HYDRAULIC RETURN TUBE
775672	JT9D	TUBE HYD CMPRSSR STATR CYL OPEN, A OF
775675	JT9D	TUBE, HYD CMPRSSR STATI CYL CLOSE, A OF
775678	JT9D	TUBE-HYD RETURN, COMPR STATOR CYL, A OF
775708	JT9D	TUBE FUEL OIL COOLER INLET, A OF
775808	JT9D	TUBE OIL VENT #3 BRG INNER INTERNAL, A OF

PART #	ENG #	NOMENCLATURE
775817	JT9D	TUBE SUPPLY FUEL PRIMARY LOWER, A OF
775820	JT9D	TUBE SUPPLY FUEL SECONDARY LOWER, A OF
775823	JT9D	TUBE ASSY
775877	JT9D	TUBE-SCAVENGE,ANGLE GEARBOX, AOF
775882	JT9D	TUBE, SCAVENGE #3 BEARING UPPER, A OF
775882	JT9D	TUBE, SCAVENGE #3 BEARING LOWER, A OF
775889	JT9D	TUBE ASSY
775951	JT9D	TUBE, PS5 AIRFRAME, A OF
775954	JT9D	TUBE PS5 AIRFRAME OUTER INTERNAL, ASSY OF
776062	JT9D	MANIFOLD
776114	JT9D	MANIFOLD
776118	JT9D	TUBE ASSY
776121	JT9D	TUBE,SCAV, #4 BRG REAR
776125	JT9D	TUBE,AIR SUPPLY, #2 BRG SEAL
776144	JT9D	MANIFOLD BREATHER, MAIN BEARING, ASSY OF
776147	JT9D	TUBE ASSY
776149	JT9D	TUBE AIR SUPPLY #4 BEARING SEAL REAR, A OF
776166	JT9D	TUBE ASSY
776171	JT9D	TUBE DRAIN #3 BEARING INTERMEDIATE, A OF
776186	JT9D	MANIFOLD SPY TRBINE CASE COOLING AIR VLV, A OF
776225	JT9D	TUBE, SUPPLY FUEL PRIMARY LEFT, A OF
776228	JT9D	TUBE-SUPPLY, FUEL, SECONDARY, LEFT,A OF
776248	JT9D	TUBE PRESSURE #3 BEARING, ASSY OF
776251	JT9D	TUBE, PRESSURE #4 BEARING, ASSY OF
776256	JT9D	MANIFOLD PRSSRE #3 & 4 BEARING, ASSY OF
776424	JT9D	TUBE ASSY
777486	JT9D	TUBE ASSY
777487	JT9D	TUBE ASSY
777557	JT9D	TUBE-SUPPLY, FUEL, SECONDARY, RIGHT,A OF
777634	JT9D	TUBE, OIL PRESSURE GEARBOX
777865	JT9D	PRIMARY FUEL NOZZLE SUPPLY TUBE
777703	JT9D	MANIFOLD SUPPLY, BLD DRCTNAL CONTRL VLV A OF
777714	JT9D	TUBE-AIR SUPPLY, #4 BRG SEAL, FRNT, ASSY OF
777866	JT9D	FUEL SUPPLY TUBE
777868	JT9D	TUBE, PS4 BLD CNTRL VLV REAR, A OF
777871	JT9D	FUEL, SUPPLY NOZ PRI
778039	JT9D	TUBE ASSY
778712	JT9D	TUBE ASSY
778716	JT9D	TUBE,PS4,TRBNE CASE COOLING AIR VLV RIGHT, A OF
778864	JT9D	TUBE PS4, FUEL CONTROL UPPER, A OF

PART #	ENG #	NOMENCLATURE
778866	JT9D	TUBE-FUEL DRAIN, OIL COOLER, UPPER ASSY OF
778868	JT9D	TUBE-FUEL DRAIN, OIL COOLER, LOWER, A OF
778916	JT9D	TUBE, FUEL CONTROL, HYD RETURN
778918	JT9D	TUBE PT2 FUEL CONTROL OUTLET, A OF
779188	JT9D	TUBE ASSY
779304	JT9D	TUBE PRESSURE #3 BRG OUTLET INTERNAL, A OF
779305	JT9D	TUBE, SCAVENGE #3 BEARING INTERNAL, A OF
779306	JT9D	TUBE ASSY
779308	JT9D	#3 BEARING OUTER INTERNAL PRESSURE TUBE
779311	JT9D	TUBE ASSY
779313	JT9D	#3 INTRNAL BEARING SCAVENGE TUBE
779316	JT9D	#3 BRG PRESSURE TUBE
780254	JT9D	TUBE,BREATHER#3 BERING, INTERNAL, A OF
780455	JT9D	TUBE DRAIN #3 BEARING FRONT, ASSY OF
780587	JT9D	OIL COOLER OUTLET FUEL TUBE
780593	JT9D	MANIFOLD-PRESSURE #1 & 2 BEARING, A OF
780595	JT9D	#4 & 4 BRG UPPER PRESS MANIFOLD
780953	JT9D	MANIFOLD-PRESSURE #1 & 2 BEARING, A OF
780851	JT9D	TUBE PS5 AIRFRAME REAR, ASSY OF
781018	JT9D	PRESS FUEL CONT TT2 SENSOR TUBE
781049	JT9D	FUEL SIGNAL TUBE ASSY
781106	JT9D	TUBE ASSY
781125	JT9D	TUBE ASSY
781127	JT9D	TUBE ASSY
781142	JT9D	TUBE ASSY
781224	JT9D	TUBE ASSY
781225	JT9D	TUBE ASSY
781228	JT9D	MANIFOLD FUEL SECNDARY RIGHT, ASSY OF
781243	JT9D	TUBE ASSY
781246	JT9D	TUBE ASSY
781255	JT9D	MANIFOLD SPY, BLD LINEAR VLV, ASSY OF
781782	JT9D	TUBE ASSY
782805	JT9D	TUBE AIR VENT #3 BEARING LEFT, ASSY OF
782808	JT9D	TUBE AIR VENT #3 BEARING LEFT, ASSY OF
782811	JT9D	#3 BREG AIR VENT TUBE
782830	JT9D	TUBE ASSY
782847	JT9D	TUBE ASSY
782848	JT9D	HYD. PRESSURE TUBE
782867	JT9D	TUBE, LWR LEFT FRNT CLG AIR TRB LH SIDE
782994	JT9D	TUBE ASSY

PART #	ENG #	NOMENCLATURE
783207	JT9D	TUBE ASSY
783208	JT9D	TUBE ASSY
783209	JT9D	#3 BRG SCAVENGE TUBE
783386	JT9D	SECONDARY FUEL SUPPLY MANIFOLD
783391	JT9D	MNFLD FUEL SGNL LOWER LEFT
783398	JT9D	TUBE ASSY
783617	JT9D	TUBE ASSY
783620	JT9D	TUBE ASSY
783661	JT9D	TUBE ASSY
783715	JT9D	NO. 1&2 BRG BRATHER MANIFOLD
783717	JT9D	#1&2 BRG BREATHER TUBE
783719	JT9D	#2 BEARING BREATHER TUBE
784766	JT9D	TUBE ASSY
784767	JT9D	TUBE ASSY
784933	JT9D	TUBE,FUELSIGNAL, BLD VLV CNTRL, ASSY OF
784965	JT9D	TUBE ASSY
784994	JT9D	FUEL MANIFOLD
785068	JT9D	TUBE ASSY
785070	JT9D	TUBE ASSY
785210	JT9D	#4 BRG SCAVENGE TUBE
785239	JT9D	TUBE ASSY
785249	JT9D	TUBE ASSY
785250	JT9D	TUBE ASSY
785251	JT9D	TUBE ASSY
785316	JT9D	TUBE ASSY
785372	JT9D	MANIFOLD SUPPLY AIR SHUTOFF VLV, ASSY OF
785373	JT9D	TUBE ASSY
785534	JT9D	TUBE ASSY
785543	JT9D	TUBE SCAVENGE, #4 BRG OUTER INTERNAL, A OF
785544	JT9D	#4 BRG PRESSURE TUBE
785756	JT9D	MANIFOLD, HYD RETURN FUEL PUMP INLET
785769	JT9D	MANIFOLD SUPPLY AIR SHUTOFF VLV, ASSY OF
785781	JT9D	TUBE ASSY
785814	JT9D	TUBE ASSY
785815	JT9D	TUBE ASSY
785834	JT9D	TUBE ASSY
785838	JT9D	TUBE ASSY
786941	JT9D	#3 BEARING BREATHER TUBE
787379	JT9D	TUBE-PS5, AIRFRAME, ASSY OF
787446	JT9D	CONNECTOR ASSEMBLY

PART #	ENG #	NOMENCLATURE
791734	JT9D	CONNECTOR ASSEMBLY
792143	JT9D	MANIFOLD-BREATHER, MAIN BEARING,ASSY OF
792381	JT9D	HYDRAULIC RETURN MANIFOLD
792807	JT9D	TUBE ASSY
792838	JT9D	TUBE ASSY
793198	JT9D	TUBE ASSY
793279	JT9D	TCC MANIFOLD
793322	JT9D	PROBE
793543	JT9D	TUBE ASSY
794475	JT9D	#3 BRG SCAVENGE TUBE
794478	JT9D	#3 BRG PRESSURE TUBE
794813	JT9D	TURB CASE COOLING MANIFOLD
795254	JT9D	TUBE ASSY
795325	JT9D	TUBE ASSY
796643	JT9D	MNFLD-CLG, TURB CASE, ASSY OF
798430	JT9D	TUBE ASSY
799334	JT9D	TUBE A OF, CLG, AIR, TURB, UPPER, LEFT FRONT
799404	JT9D	TUBE, SUPPLY BLB VLV CYL, OPEN REAR, A OF
799421	JT9D	TUBE ASSY
799488	JT9D	TURBINE COOLING MANIFOLD
801291	JT9D	FUEL, OIL COOLER INLET ASSY OF
801327	JT9D	TUBE ASSY
801682	JT9D	INTERNAL SCAVENGE TUBE
801725	JT9D	MANIFOLD
802698-01	JT9D	TUBE,PS4 CONT PSTRCTR INLET FRONT, ASSY OF
802716	JT9D	TUBE AIR VENT #3 BRG ASSY OF
803585-01	JT9D	TUBE SUPPLY TCC VALVE ASSY OF
803586-01	JT9D	TUBE SUPPLY TCC VALVE ASSY OF
803588-01	JT9D	MNFLD-SUPPLY,TCC VALVE, ASSY OF
803736	JT9D	CLG, TURB, CASE MNFLD
804119-01	JT9D	TUBE ASSY
804120-01	JT9D	TUBE ASSY
804216-01	JT9D	TUBE PS4 REAR UPPER ASSY
804220-01	JT9D	TUBE PS4 REAR LOWER ASSY
804237	JT9D	MANIFOLD, SUPPLY AIR SHUT OFF VALVE
804668-01	JT9D	TUBE-FUEL, OIL COOLER INLET, ASSY OF
804977	JT9D	TUBE, LWR RH REAR CLG AIR TURB RH SIDE
804978	JT9D	TURBINE COOLING TUBE
805081	JT9D	TCC MANIFOLD
805411-01	JT9D	TUBE ASSY

PART #	ENG #	NOMENCLATURE
805979	JT9D	TUBE ASSY
807707	JT9D	OIL COOLER INLET FUEL TUBE
807710	JT9D	TUBE-FUEL PRESSURIZING & DUMP VLVE
807712	JT9D	REOP FROM 647312 PER S/B 5901
807716	JT9D	SECONDARY FUEL SUPPLY TUBE
809318-01	JT9D	UPPER TURBINE COOLING AIR TUBE
809319-01	JT9D	LOWER TURBINE COOLING AIR TUBE
809322-01	JT9D	UPPER TCA TUBE
809323-01	JT9D	UPPER TCA TUBE
810247	JT9D	TUBE ASSY
810461	JT9D	MNFLD ASSY, FRNT MAIN BRG DIFFUSER
810549-01	JT9D	TUBE, SUPPLY FUEL NOZZLE PRIMARY
810555-01	JT9D	TUBE, SUPPLY FUEL NOZZLE PRIMARY
810556-01	JT9D	TUBE, SUPPLY FUEL NOZZLE PRIMARY
810559-01	JT9D	TUBE, SUPPLY FUEL NOZZLE PRIMARY
810560-01	JT9D	TUBE, SUPPLY FUEL NOZZLE PRIMARY
810561-01	JT9D	TUBE, SUPPLY FUEL NOZZLE PRIMARY
810562-01	JT9D	TUBE, SUPPLY FUEL NOZZLE PRIMARY
810564-01	JT9D	TUBE, SUPPLY FUEL NOZZLE PRIMARY
810565-01	JT9D	TUBE, SUPPLY FUEL NOZZLE PRIMARY
810566-01	JT9D	TUBE, SUPPLY FUEL NOZZ; #19 POSITION
810568-01	JT9D	TUBE, SUPPLY FUEL SECONDARY
810569-01	JT9D	TUBE, SUPPLY FUEL SECONDARY
810574-01	JT9D	TUBE, SUPPLY FUEL NOZZ; # 5 POSITON
810575-01	JT9D	TUBE, SUPPLY FUEL NOZZ; # 6 POSITION
810576-01	JT9D	TUBE, SUPPLY FUEL SECONDARY
810577-01	JT9D	TUBE, SUPPLY FUEL NOZZ; #8 POSITION
810578-01	JT9D	TUBE, SUPPLY FUEL SECONDARY
810580-01	JT9D	TUBE, SUPPLY FUEL SECONDARY
810581-01	JT9D	TUBE, SUPPLY FUEL SECONDARY
810583-01	JT9D	TUBE, SUPPLY FUEL SECONDARY
810584-01	JT9D	TUBE, FUEL, NOZZ SEC FOR INCREASE OILC
810586-01	JT9D	TUBE, SUPPLY FUEL SECONDARY
810588-01	JT9D	TUBE, SUPPLY FUEL SECONDARY
810589-01	JT9D	TUBE, SUPPLY FUEL SECONDARY
811790-01	JT9D	TUBE ASSY
814310-01	JT9D	TUBE ASSY
814311-01	JT9D	TUBE ASSY
815974-01	JT9D	PS5 AIRFRAME DIFFUSER CASE